

DIGITAL DRIVER IN DIN-RAIL FORMAT EN 60715

Valve model:
directional, pressure and flow valves without transducer

Driver model:
E-BM-AS

IDENTIFICATION

Driver identification label

Driver label : L

1 : driver code
2 : driver serial number
3 : factory firmware version

INSTALLATION TOOLS

Screwdriver	DIN-rail EN60715	Connectors
not included	not included	supplied with the driver
see STEP 1		see STEP 2.1

PROGRAMMING TOOLS - not included

PC software	Serial RS232 connection KIT
E-SW-SETUP	E-C-PS-DB9/RJ45
	Adapter
	E-A-PS-USB/DB9

PC SOFTWARE

E-SW-SETUP	supports NP (USB)	IL (IO-Link)	PS (Serial)	IR (Infrared)
	BC (CANopen)	BP (PROFIBUS DP)	EH (EtherCAT)	
	EW (POWERLINK)	EI (EtherNet/IP)	EP (PROFINET RT/IRT)	
	supports valves with SP, SF, SL alternated p/Q control			

REMARK Atos PC software is designed for Windows based operative systems - Windows 10 or later

PC SOFTWARE DOWNLOAD

Download PC software at www.atos.com accessing to "MyAtos -> Download area electronics"

Free registration by filling the form at www.atos.com/en-it/login

E-SW-SETUP is free and available in Download area

RELATED DOCUMENTATION - www.atos.com

FS900 Operating and maintenance information - tech. table	E-MAN-BM-AS E-BM-AS - driver operating manual
F** Proportional valves without transducer - tech. table	
P005 Mounting surfaces - tech. table	
G030 E-BM-AS drivers - tech. table	
GS500 Programming tools - tech. table	
K800 Electric and electronic connectors - tech. table	


ATTENTION !

The purpose of this quickstart guide is show a logical sequence of basic operations. This guide does not cover all details or variants of Atos valves. All operations described in this document should be performed only by qualified personnel. Operations and images could be subject to change without notice. For further information please refer to related documentation.

CONTACT US

Atos spa - Italy - 21018 Sesto Calende www.atos.com support@atos.com

PRODUCTS OVERVIEW



INSTALLATION		OPTIONAL	
STEP 1	STEP 2	STEP 3	STEP 4
INSTALLATION	ELECTRICAL	DIGITAL vs ANALOG	PC SOFTWARE

STEP 1 INSTALLATION

To unlock the driver from the DIN rail:
1. pull down the locking slide with a screwdriver
2. rotate up the driver

To wire cables in the connectors:
1. press the button with a screwdriver
2. insert the cable termination

Note: max conductor size 2,5 mm²

STEP 2 ELECTRICAL

This section considers the different valves options, illustrating the multiple variants of the available electrical connections. The electrical connections have to be wired according to the selected valve code

2.1 CONNECTORS

Recommended LiVCY shielded cables, max length 40 m: 0,5 mm² for logic - 1,5 mm² for power supply and solenoids

Connector A	Connector C	/P option
A1 SOL S1 (Current to solenoid S1)	C1 DI1 (input 24Voc) (1)	
A2	C2 DI2 (input 24Voc) (1)	
A3 SOL S2 (Current to solenoid S2)	C3 DI3 (input 24Voc) (1)	+5Voc 10mA output supply
A4	C4 DI4 (input 24Voc) (1)	-5Voc 10mA output supply


Connector B	/P option
B1 CMD1 (±10Voc / 4 + 20mA)	D1 V+ (power supply 24Voc) (1)
B2 CMD- (ground for reference) Reference for ±5Voc output	D2 V0 (power supply 0Voc)
B3 CMD2 (±10Voc / 4 + 20mA)	D3 ENABLE (input 24Voc) (1)
B4 DGND (optical insulated ground for on/off inputs DI1 ÷ DI4)	D4 STATUS (output 24Voc) (1)

WARNING: remove power supply before any electrical or wiring operations


WARNING: a safety fuse is required in series to driver power supply - 2,5 A time lag fuse

ELECTRICAL WIRING EXAMPLES


REFERENCE INPUTS - VOLTAGE




REFERENCE INPUTS - CURRENT



EXTERNAL POTENTIOMETER(S) - only for /P option



PRESSURE TRANSDUCER - only for /W option




STEP 3 DIGITAL vs ANALOG - only for E-BM-AS series 12 or higher

E-BM-AS digital driver replaces the E-BM-AC and E-ME-AC


3.1 E-BM-AC / E-ME-AC ELECTRICAL CONNECTIONS QUICK REPLACEMENT

Disconnect the cables from E-BM-AC or E-ME-AC analog driver and connect them to the E-BM-AS digital driver connectors.


POWER SUPPLY AND ENABLE




COILS



EXTERNAL POTENTIOMETERS - only for /P option




EXTERNAL REFERENCE



E-BM-AC

Socket type: E-K-11B

Undecal




PIN	SIGNALS
1	Power supply V+
2	R1 Input Signal -
3	R1 Input Signal +
4	Coil S2
5	Coil S2
6	+5V Ext. power supply
7	-5V Ext. power supply
8	R2 Input Signal -
9	R2 Input Signal +
10	Coil S1
11	Power supply V+

E-ME-AC

Socket type: E-K-32M

Eurocard DIN 41612




PIN	SIGNALS
2	Power supply V+
4	Power supply V+
6	Ramp SW off
8	Signal GND
10	+5V Ext. p.s.
12	-15V Ext. Ref. Sign.
14	Signal GND
16	-5V Ext. p.s.
18	Enable
20	Ref. Invers.
22	Ref. Com.
24	Ref. 4
26	Ref. 1
28	Ref. 2
30	Coil S1
32	Coil S2

3.2 E-BM-AS COMPATIBILITY FUNCTIONALITIES ACTIVATION



E-BM-AS digital inputs (DI1..DI4) activate compatibility functionalities with E-BM-AC and E-ME-AC analog drivers.

COMPATIBILITY MODE - for E-BM-AC 01F/05F or E-ME-AC 01F/05F




REMARK:
• To activated compatibility mode connect 24 Vcc (1) to DI1 (pin C1) before driver power on
• Reference Inversion and Ramp Off functionality are available only if this compatibility mode is activated


REFERENCE INVERSION - DEACTIVATED



RAMP OFF - ACTIVATED




RAMP OFF - DEACTIVATED



(1) 12 Vcc for /12 option - not available for E-ME-AC (2) Do not connect

COMPATIBILITY MODE - for E-BM-AC 011F (not available for /P option)



REMARK:
• To activated compatibility mode connect 24 Vcc (1) to DI4 (pin C4) before driver power on

(1) 12 Vcc for /12 option

STEP 4 PC SOFTWARE


REMARK off-board drivers are factory preset with default parameters and ready to use after piping and electrical connections. **Play with parameters is optional, not mandatory!**

4.1 CONNECTION

1 In order to access valve parameterization:

- Install E-SW-SETUP software on PC
- Complete the electrical installation and power on the driver with 24Vdc (standard) or 12Vdc (/12 option)

2 Connect driver to the PC as shown below



WARNING: drivers RS232 port is not isolated!


3 Launch the PC software using E-SW-SETUP icon:

- PC software does NOT detect valid connection communication is not established, please follow wizard procedure
- PC software detects valid connection communication automatically established - valve is ON-LINE see




4 In ON-LINE - Wizard press button:

- a) **CABLE CONNECTION** Wizard procedure for connection via USB cable



NOTE: Bluetooth not available for E-BM-AS

5 Communication established, valve is ON-LINE and it is possible change parameters



4.2 CONFIGURATION


<p>Single solenoid directional control valve, 2 positions with positive overlapping</p>	<p>Double solenoid directional control valve, 3 positions with positive overlapping</p>	<p>Single or double solenoid directional control valve, 3 positions with zero overlapping</p>
<p>BiasP positive bias ScaleP positive scale</p> <p>Threshold = 2% (200mV or 0,32mA for /I option)</p>	<p>BiasP positive bias ScaleP positive scale BiasN negative bias ScaleN negative scale</p> <p>Threshold = 2% (±200mV or ±0,16mA for /I option)</p>	<p>ScaleP positive scale ScaleN negative scale Offset</p>

BIAS AND SCALE - 2 and 3 POSITION VALVES

Bias setting: supply input signal just over the Threshold value; increase the Bias until the actuator is start moving, then lightly reduce the Bias just to stop the actuator

Scale setting: supply the max input signal; adjust the Scale to obtain the max actuator speed


NOTE: bias and scale negative parameter are available only for 3 position valves



OFFSET AND SCALE - 3 POSITION VALVES, ZERO OVERLAP

Offset setting: supply the input signal equal to 0%; adjust the Offset until the actuator is stopped

Scale setting: supply the max input signal (positive/negative); adjust the Scale to obtain the max actuator speed in both directions



RAMPS


Ramps setting: select required ramp configuration and adjust ramp time to optimize the actuator's acceleration and deceleration

No Ramp : no ramps selected

Double Ramp : setup Ramp 1 and 2

Single Ramp : setup Ramp 1


Four Ramps : setup Ramp 1, 2, 3 and 4 (only 3 position)



DITHER

Dither setting: factory default 200 Hz

- lower frequencies reduce the hysteresis of the valve, too low values can affect the valve stability
- higher frequencies increase regulation stability, but increase also the hysteresis of the valve



REFERENCE ANALOG INPUT RANGE - E-SW-SETUP

Reference input signal can be selected between different options.

Defaults: 0 ± 10 V for standard and 4 ± 20 mA for /I option.

Input signal is configurable via software selecting between voltage and current, browsing to **Reference** page:

select **Signal Range** control to set the analog input signal

NOTE: if different settings are required use **Custom** option

4.3 STORE

Parameters modifications will be stored into driver permanent memory:

- press **Store User** button to store **Valve Parameters**

WARNING: during valve parameters storing operations, the driver automatically shuts down the solenoid power supply for a short time. Do not perform any storing commands while the system is working.

4.4 BACK UP

Parameter modifications will be saved into PC memory:

- press **Save** button to access **Computer SW Archive - Setting Files** page, **Setting File Name** pop-up appears
- input a valid name into **Description** field and press **Ok** button

TROUBLESHOOTING

Valve vibration or noise

- presence of air in the solenoid; perform valve air bleeding procedure – see tech. table of the connected valve
- dither frequency too low; increase value of the frequency – see STEP 4, section 4.2

The valve does not follow the reference signal

- driver is powered off, verify presence of 24 Vdc (standard) or 12 Vdc (/12 option) power supply and the coil(s) connection
- driver is disabled, verify presence of 24 Vdc (standard) or 12 Vdc (/12 option) on enable pin
- flow/pressure values exceeding the valve's performance limits, verify that hydraulic operating conditions are in compliance with the valve's characteristics
- big hysteresis or spool stick-slip, reduce the dither frequency
- spool sticking, contact Atos service center

PC software parameters modifications are lost when valve is switched off

- parameter store operation was not performed, check store procedure – see STEP 4, section 4.3

PC software parameters modifications have no effect on the valve

- driver is OFF LINE, check connection procedure – see STEP 4, section 4.1

After the modifications of PC software parameters the valve/driver does not work properly

- restore driver factory parameters using 'Restore Factory' button, located in 'Signals - Extended Page' window:
 - during restore, the current to the solenoid(s) will be temporarily switched to off!
 - factory parameters will be applied at next driver restart or after power off-on sequence!
 - perform the bias and scale configurations again!