


## PILOTED OPERATED PROPORTIONAL DIRECTIONAL VALVES

Valve model:  
DPZO-AEB-1    DPZO-AEB-2    DPZO-AEB-4    DPZO-AEB-6


Driver model:  
E-RI-AEB

## IDENTIFICATION

Valve identification plates and label




Valve name plate : **M**




1 : valve code  
2 : valve matrix code  
3 : valve hydraulic symbol

Pilot valve name plate : **N**









4 : pilot valve code  
5 : pilot valve matrix code  
6 : pilot hydraulic symbol

Driver label : **L**








7 : driver code  
8 : driver serial number  
9 : factory firmware version

## INSTALLATION TOOLS ACCORDING TO VALVE MODEL- not included

Fastening bolts	Wrenches	Main connectors		Transducer cable	IO-Link connector IL
					
see STEP 1 and STEP 3		see STEP 2.1		see STEP 2.2	see STEP 2.3

## PROGRAMMING TOOLS - not included

PC software	mobile App	Bluetooth Adapter	OR	USB connection KIT	
					
E-SW-SETUP	Atos CONNECT	E-A-BTH		E-C-SB-USB/M12	E-A-SB-USB/OPT


NOTE: Atos CONNECT supports Atos digital valve drivers equipped with E-A-BTH or with built-in Bluetooth, see STEP 5

## PC SOFTWARE

E-SW-SETUP	supports	NP (USB)	IL (IO-Link)	PS (Serial)	IR (Infrared)
		BC (CANopen)	BP (PROFIBUS DP)	EH (EtherCAT)	
		EW (POWERLINK)	EI (EtherNet/IP)	EP (PROFINET RT/IRT)	
	supports	valves with SP, SF, SL alternated p/Q control			

REMARK Atos PC software is designed for Windows based operative systems - Windows 10 or later

## PC SOFTWARE DOWNLOAD



Download PC software at [www.atos.com](http://www.atos.com) accessing to "MyAtos -> Download area electronics"

Free registration by filling the form at [www.atos.com/en-it/login](http://www.atos.com/en-it/login)

E-SW-SETUP is free and available in Download area

## RELATED DOCUMENTATION - [www.atos.com](http://www.atos.com)

<b>FS900</b> Operating and maintenance information - tech. table	<b>STARTUP BLUETOOTH</b> Bluetooth adapter startup guide
<b>FS170</b> DPZO positive spool overlap - tech. table	<b>E-MAN-RI-AEB</b> AEB - driver operating manual
<b>P005</b> Mounting surfaces - tech. table	<b>E-MAN-S-IL</b> IO-Link protocol programming manual
<b>GS500</b> Programming tools - tech. table	
<b>GS520</b> IO-Link features - tech. table	
<b>K800</b> Electric and electronic connectors - tech. table	

## ATTENTION !

The purpose of this quickstart guide is show a logical sequence of basic operations. This guide does not cover all details or variants of Atos valves. All operations described in this document should be performed only by qualified personnel. Operations and images could be subject to change without notice. For further information please refer to related documentation.

## CONTACT US


Atos spa - Italy - 21018 Sesto Calende

[www.atos.com](http://www.atos.com)

[support@atos.com](mailto:support@atos.com)

## PRODUCTS OVERVIEW


STEP 1




STEP 2.2

STEP 4

STEP 3



STEP 2.3




NP

IL

INSTALLATION			PROGRAMMING	
STEP 1	STEP 2	STEP 3	STEP 4	STEP 5
MECHANICAL	ELECTRICAL	HYDRAULICS	PC SOFTWARE	MOBILE APP

## STEP 1 MECHANICAL



In case of first commissioning, before the valve installation the whole system must be correctly flushed to grant the required cleanliness level:  
During the flushing operation use on-off or by-pass valves in place of the proportional valve


- remove protection pad **P1** located on the valve bottom face only immediately before installation (do not remove connectors caps)
- check the presence and correct positioning of the seals on valve ports
- verify that valve mounting surface is clean and free from damages or burrs
- verify the correct valve orientation according to the pattern of the relevant mounting interface
- lock the fastening bolts respecting below sequence and tightening torque according to valve model

**DPZO-AEB-\*-1**


Mounting surface layout

4401-05-05-0-05

Valve size ISO 4401: 10




Fastening bolts  
socket head screws



n°4 M6x40  
class:12.9

wrench  
5 mm

Tightening torque: 15 Nm




**DPZO-AEB-\*-2**


Mounting surface layout

4401-07-07-0-05

Valve size ISO 4401: 16



Fastening bolts  
socket head screws




n°4 M10x50  
class:12.9

n°2 M6x45  
class:12.9

wrench  
5 mm

wrench  
8 mm

Tightening torque:  
15 Nm for M6  
70 Nm for M10




**DPZO-AEB-\*-4**


Mounting surface layout

4401-08-08-0-05

Valve size ISO 4401: 25




Fastening bolts  
socket head screws



n°6 M12x60  
class:12.9

wrench  
10 mm

Tightening torque: 125 Nm




**DPZO-AEB-\*-6**


Mounting surface layout

4401-10-09-0-05

Valve size ISO 4401: 32




Fastening bolts  
socket head screws



n°6 M20x90  
class:12.9

wrench  
17 mm

Tightening torque: 600 Nm




## STEP 2 ELECTRICAL


This section considers the different valves options, illustrating the multiple variants of the available electrical connections. The electrical connections have to be wired according to the selected valve code

## 2.1 MAIN CONNECTOR - only for NP


1 Remove main connector cap **P2**



2 Select main connector according to valve code and proceed with wirings operations




Recommended LiYCY shielded cables:  
7 x 0,75 mm² max 20 m  
7 x 1 mm² max 40 m




Recommended LiYCY shielded cable:  
12 x 0,75 mm² max 20 m

3 Connect the valve to the system



NOTE: the use of above metallic connectors is strongly recommended in order to fulfill EMC requirements



**Standard**

A	V+	(power supply 24Vdc)
B	V0	(power supply 0Vdc)
C	AGND	(input 24Vdc)
D	INPUT+	(±10Vdc / 4 ÷ 20mA)
E	INPUT-	(±10Vdc / 4 ÷ 20mA)
F	MONITOR	(±5Vdc 1V=1A)
G	EARTH	

**/Z and /W options**


1	V+	(power supply 24Vdc)
2	V0	(power supply 0Vdc)
3	ENABLE	(input 24Vdc)
4	INPUT+	(±10Vdc / 4 ÷ 20mA)
5	INPUT-	(±10Vdc / 4 ÷ 20mA)
6	MONITOR	(±5Vdc 1V=1A)
7	NC	
8	NC	for /Z option
9	MONITOR2	(0 ÷ 5Vdc) for /W option
10	VL0	(logic power supply 24Vdc)
11	FAULT	(output 24Vdc)
PE	EARTH	

**/Q option**


A	V+	(power supply 24Vdc)
B	V0	(power supply 0Vdc)
C	ENABLE	(input 24Vdc)
D	INPUT+	(±10Vdc / 4 ÷ 20mA)
E	INPUT-	(±10Vdc / 4 ÷ 20mA)
F	MONITOR	(±5Vdc 1V=1A)
G	EARTH	

## 2.2 PRESSURE TRANSDUCERS CONNECTOR - only for /W option

1 Remove transducer connector cap **P3**




2 Proceed with wirings operations



**/W option**

1	VF+ 24V	(power supply 24Vdc)
2	TR	(0 ÷ 10Vdc / 4 ÷ 20mA)
3	AGND	
4	NC	
5	NC	

3 Connect the valve to the transducer)



ZH-5PM/1.5 - 1.5 m length  
ZH-5PM/5 - 5 m length  
5 pin plastic - single cable

## ELECTRICAL WIRING EXAMPLES - only for NP

**MAIN CONNECTOR - VOLTAGE**

REFERENCE INPUT - DIFFERENTIAL MODE

cabinet side	main connector pin-out	valve internal circuit
±10 Vdc	std : I/Q / Z / W	
Ref. ⊕	D 4	INPUT+ 50K
Ref. ⊖	E 5	INPUT- 50K

REFERENCE INPUT - COMMON MODE

cabinet side	main connector pin-out	valve internal circuit
±10 Vdc	std : I/Q / Z / W	
Ref. ⊕	D 4	INPUT+ 50K
Ref. ⊖	E 5	INPUT- 50K
⊥ (0 V)	C B 10	AGND / V0 / VL0

**MAIN CONNECTOR - CURRENT**

REFERENCE INPUT - DIFFERENTIAL MODE

cabinet side	main connector pin-out	valve internal circuit
4÷20 mA	std : I/Q / Z / W	
Ref. ⊕	D 4	INPUT+ Rsh = 500 ohm
Ref. ⊖	E 5	INPUT- Rsh = 500 ohm

REFERENCE INPUT - COMMON MODE

cabinet side	main connector pin-out	valve internal circuit
4÷20 mA	std : I/Q / Z / W	
Ref. ⊕	D 4	INPUT+ Rsh = 500 ohm
Ref. ⊖	E 5	INPUT- Rsh = 500 ohm
⊥ (0 V)	C B 10	AGND / V0 / VL0

## MAIN CONNECTOR - MONITORS VOLTAGE ONLY

**MONITOR OUTPUT**

cabinet side	main connector pin-out	valve internal circuit
±5 Vdc	std : I/Q / Z / W	
Mon. ⊕	F 6	MONITOR 50K
⊥ (0 V)	C B 10	AGND / V0 / VL0

**MONITOR2 OUTPUT - only for /W option**


cabinet side	main connector pin-out	valve internal circuit
0÷5 Vdc	I/W	
Mon. ⊕	8	MONITOR2
⊥ (0 V)	10	VL0

## PRESSURE TRANSDUCER - only for /W option


transducer side	transducer connector pin-out	valve internal circuit
power supply	std : I/Q	
VF+ 24V	1	VF+ 24V
AGND	3	AGND
TR	2	TR
signal		
±10Vdc / 4÷20mA		

## 2.3 IO-Link CONNECTOR - only for IL

1 Remove IO-Link connector caps **P4**




2 Proceed with wirings operations



M12 Coding A - 5 pin  
Valve port class B  
Cable diameter 6 ÷ 8 mm

3 Connect the valve to the IO-Link network of the system





ZM-5PF (metallic)  
5 PIN IO-Link CONNECTOR

**IO-Link**

1	L+	(power supply 24Vdc - IO-Link)
2	P24	(power supply 24Vdc - others) (1)
3	L-	(power supply 0Vdc - IO-Link)
4	CIO	IO-Link data-line
5	N24	(power supply 0Vdc - others) (1)

(1) max power consumption 50 W;  
for master ports class A connect P24/N24 to an external power supply

STEP 3 HYDRAULICS



Wrench type

3 mm

Tightening torque

4 Nm

**Air bleeding:**

- release 2 or 3 turns the air bleed screw **V**
- cycle the valve at low pressure until the oil leaking from the **V** port is exempted from air bubbles
- lock the air bleed screw **V**

Consult tech table **FS900** for general guidelines about component's commissioning



STEP 4 PC SOFTWARE

**REMARK** proportional valves with on-board electronics are factory preset with default parameter and ready to use after piping and electrical connections. **Play with parameters is optional, not mandatory!**

4.1 CONNECTION

- 1** In order to access valve parameterization:
- Install E-SW-SETUP software on PC
  - Insert main connector or IO-Link connector to the valve and power on with 24V<sub>DC</sub>


- 2** Remove USB plastic protection cap **P5** and connect valve to the PC as show below via Bluetooth (adapter only) or USB (cable and isolator adapter)



**WARNING: drivers USB port is not isolated!**  
The use of USB isolator adapter is highly recommended for PC protection (see **GS500**)

- 3** Launch the PC software using E-SW-SETUP icon:
- **PC software does NOT detect valid connection** communication is not established, please follow wizard procedure **4**
  - **PC software detects valid connection** communication automatically established - valve is **ON-LINE** see **5**

- 4** In **ON-LINE** - Wizard press button:
- a** : **WIRELESS CONNECTION**  
Wizard procedure for connection via Bluetooth
  - b** : **CABLE CONNECTION**  
Wizard procedure for connection via USB cable



**NOTE:** for more info about E-A-BTH Bluetooth adapter, please refer to STARTUP BLUETOOTH guide

**REMARK:** once removed the E-A-BTH Bluetooth adapter or E-C-SB-USB/M12 USB cable, screw the plastic protection cap **P5** applying the correct tightening torque, in order to preserve valve's IP protection characteristics




Tightening torque

0,6 Nm

4.2 CONFIGURATION


Single solenoid directional control valve, 2 positions with positive overlapping and flow control valve



**BiasP** positive bias  
**ScaleP** positive scale

Threshold = 2%  
(200mV or 0,32mA for /I option)

Double solenoid directional control valve, 3 positions with positive overlapping



**BiasP** positive bias  
**ScaleP** positive scale  
**BiasN** negative bias  
**ScaleN** negative scale

Threshold = 2%  
(±200mV or ±0,16mA for /I option)

BIAS AND SCALE - 2 POSITION VALVES and FLOW CONTROL VALVES

**Bias setting:** supply input signal just over the Threshold value; increase the Bias until the actuator is start moving, then lightly reduce the Bias just to stop the actuator

**Scale setting:** supply the max input signal; adjust the Scale to obtain the max actuator speed

BIAS AND SCALE - 3 POSITION VALVES

Follow the same indications reported for 2 position valves and flow controls valves for both valve's solenoids

RAMPS

**Ramps setting:** select the required ramp configuration and adjust the ramp time to optimize the actuator's acceleration and deceleration

**No Ramp** : no ramps selected

**Single Ramp** : setup **Ramp 1**

**Double Ramp** : setup **Ramp 1** and **2**

**Four Ramps** : setup **Ramp 1, 2, 3** and **4** (only 3 position)


DITHER

**Dither setting:** factory default 200 Hz

- lower frequencies reduce the hysteresis of the valve, too low values can affect the valve stability
- higher frequencies increase regulation stability, but increase also the hysteresis of the valve

WIZARD REFERENCE - E-SW-SETUP - only for NP

Reference input signal is factory preset according to selected valve code, defaults are ±10 V<sub>DC</sub> for standard and 4 ÷ 20 mA for /I option. Input signal can be reconfigured via PC software selecting between voltage and current, browsing to **Reference Analog Range** page:





press **Voltage Standard** button to automatically set the analog input signal to voltage

press **Current 4..20 mA** button to automatically set the analog input signal to current

**REMARK:** **Voltage Standard** or **Current 4..20 mA** buttons do not act on Monitor output signal configuration! For Monitor output signal configuration browse to page **Others - Monitor Output**

4.3 STORE


Parameters modifications will be stored into driver permanent memory:

- press  button to access **Driver - Memory Save** window
- press  button to store **Valve Parameters**





**WARNING:** during valve parameters storing operations, the driver automatically shuts down the solenoid power supply for a short time. Do not perform any storing commands while the system is working.

4.4 BACK UP

Parameter modifications will be saved into PC memory:

- press  button to access **Computer SW Archive - Setting Files** page, **Setting File Name** pop-up appears
- input a valid name into **Description** field and press **Ok** button

STEP 5 MOBILE APP



**ATOS CONNECT** for smartphones and tablets is a free downloadable app which allows quick access to valve main functional parameters and configuration via Bluetooth, thus avoiding physical cable connection and significantly reducing commissioning times.


**ATOS CONNECT** app requirements:


- iOS 14 / Android 9
- Bluetooth Low Energy (BLE), version 4.2 or higher
- Atos digital valves/drivers equipped with E-A-BTH Bluetooth adapter or with built-in Bluetooth


HINT ! - Wizard objects dictionary - only for IL


Press **CTRL + H** on the PC keyboard to open the context help form

Move arrow on parameter (e.g. **Ramp Type**) to display the objects dictionary information to access the parameter via IO-Link

If present **List**, press  to display values accepted by the parameter





**NOTE:** alternatively right click on any parameter 

TROUBLESHOOTING

Valve vibration or noise

- presence of air in the solenoid; perform air bleeding procedure – see STEP 3
- dither frequency too low; increase value of the frequency – see STEP 4.2

The valve does not follow the reference signal

- valve is powered off, verify presence of 24 V<sub>DC</sub> power supply
- valve is disabled, verify presence of 24 V<sub>DC</sub> on enable pin - only for /Q, /Z and /W options
- flow/pressure values exceeding the valve's performance limits, verify that hydraulic operating conditions are in compliance with the valve's characteristics
- big hysteresis or spool stick-slip, reduce the dither frequency
- spool sticking, contact Atos service center
- missing piloting pressure, verify that hydraulic power level is compliant with valve's characteristics
- wrong pilot/drain configuration - check if the pilot/drain configuration of the valve corresponds to the effective system layout

PC software parameters modifications are lost when valve is switched off

- parameter store operation was not performed, check store procedure – see STEP 4, section 4.3

PC software parameters modifications have no effect on the valve

- valve is OFF LINE, check connection procedure – see STEP 4, section 4.1

After the modifications of PC software parameters the valve does not work properly

- restore valve factory parameters using 'Load Factory Set' button, located in 'Driver - Memory Save' window:
  - during restore, the current to the solenoid(s) will be temporarily switched to off!
  - factory parameters will be applied at next driver restart or after power off-on sequence!