

**DIN-RAIL DIGITAL DRIVER FOR DIRECTIONAL AND FLOW VALVES**

<b>Industrial driver models:</b> E-BM-TES/LES-N without alternated P/Q control <b>SN</b> E-BM-TES/LES-S with alternated P/Q control <b>SP, SF, SL</b>	<b>Ex-Proof driver models:</b> E-BM-TES/LES-N /A without alternated P/Q control <b>SN</b> E-BM-TES/LES-S /A with alternated P/Q control <b>SP, SF, SL</b>
<b>Industrial valve models:</b> Direct operated DLHZO-T DHZO-T QVHZO-T DLKZOR-T DKZOR-T QVKZOR-T Pilot operated DPZO-T LIQZP-L DPZO-L	<b>Ex-Proof valve models:</b> Direct operated DLHZA-T DHZA-T QVHZA-T DLKZA-T DKZA-T QVKZA-T Pilot operated DPZA-T LIQZA-L DPZA-L

**IDENTIFICATION**

Driver identification label

Driver label : L

- 1 : driver code
- 2 : factory set code
- 3 : driver serial number
- 4 : factory firmware version

**INSTALLATION TOOLS**

<b>Screwdriver</b> not included	<b>DIN-rail EN60715</b> not included	<b>Connectors</b> supplied with the driver see STEP 2
------------------------------------	---	---

see STEP 1

**PROGRAMMING TOOLS - not included**

<b>Software</b> E-SW-* programming software	<b>USB connection KIT</b> Cable E-C-SB-USB/BM Isolator E-A-SB-USB/OPT	<b>OR</b>	<b>Bluetooth connection KIT</b> Cable E-C-SB-BM/BTH Adapter E-A-SB-USB/BTH
--	---	-----------	--

**PROGRAMMING SOFTWARE**

The software is available in different versions according to the driver's options:

<b>E-SW-BASIC</b>	supports <b>NP</b> (USB)	<b>IL</b> (IO-Link)	<b>PS</b> (Serial)	<b>IR</b> (Infrared)
<b>E-SW-FIELDBUS</b>	supports <b>BC</b> (CANopen)	<b>BP</b> (PROFIBUS DP)	<b>EH</b> (EtherCAT)	<b>EP</b> (PROFINET RT/IRT)
<b>E-SW-/PQ</b>	supports drivers with <b>SP, SF, SL</b> alternated P/Q control			

E-SW-FIELDBUS supports also drivers without fieldbus communication; E-SW-/PQ supports also drivers without P/Q control

**REMARK** Atos software is designed for Windows based operative systems - Windows XP SP3 or later

**DOWNLOAD AREA**

Perform the registration at [www.atos.com/en-it/login](http://www.atos.com/en-it/login) by filling the form. In MyAtos area, perform login with personal username and password and then press the **Download area electronics** button

Free version of E-SW-BASIC can be downloaded and used by the "FREE Activation Code"

The software remains active for 10 days from the installation date and then it stops until the user inputs the Activation Code

**RELATED DOCUMENTATION - www.atos.com - section Catalog on-line**

<b>FS900</b> Operating and maintenance information - tech. table	<b>STARTUP E-SW-BASIC</b> Software startup guide
<b>F***</b> Proportional valves with one or two LVDT - tech. table	<b>STARTUP E-SW-FIELDBUS</b> Software startup guide
<b>P005</b> Mounting surface - tech. table	<b>STARTUP BLUETOOTH</b> Bluetooth adapter startup guide
<b>GS240</b> E-BM-TES/LES drivers - tech. table	<b>E-MAN-BM-LES</b> TES/LES - driver operating manual
<b>GS500</b> Programming tools - tech. table	<b>E-MAN-BM-LES-S</b> TES/LES - driver with S option operating manual
<b>GS510</b> Fieldbus - tech. table	<b>E-MAN-S-BC</b> CANopen protocol programming manual
<b>K800</b> Electric and electronic connectors - tech. table	<b>E-MAN-S-BP</b> PROFIBUS DP protocol programming manual
	<b>E-MAN-S-EH</b> EtherCAT protocol programming manual
	<b>E-MAN-S-EW</b> POWERLINK protocol programming manual
	<b>E-MAN-S-EI</b> EtherNet/IP protocol programming manual
	<b>E-MAN-S-EP</b> PROFINET protocol programming manual

**ATTENTION !**

The purpose of this quickstart guide is show a logical sequence of basic operations. This guide does not cover all details or variants of Atos valves. All operations described in this document should be performed only by qualified personnel. Operations and images could be subject to change without notice. For further information please refer to related documentation.

**CONTACT US**

**PRODUCTS OVERVIEW**

**STEP 1** MECHANICAL

**STEP 2** ELECTRICAL

**STEP 3** SOFTWARE

INSTALLATION		PROGRAMMING
STEP 1	STEP 2	STEP 3
MECHANICAL	ELECTRICAL	SOFTWARE

**STEP 1 MECHANICAL**

**To lock the driver from the DIN rail:**

1. place the attach located on the driver bottom on the DIN rail
2. press the driver against the DIN rail until the locking slide clicks

**To unlock the driver from the DIN rail:**

1. pull down the locking slide with a screwdriver
2. rotate up the driver

**To extract the connectors:**

1. push lever
2. pull connector

**To insert the connectors:**

1. push the connector in its slot

**To wire cables in the connectors:**

1. insert the cable termination
2. turn screw with a screwdriver

**NOTE:** max conductor size 2,5 mm<sup>2</sup> tightening torque 0,4 ÷ 0,6 Nm

**NOTE:** all connectors are supplied with a mechanical coding. This feature ensures a unique insertion of each connector in the own slot (e.g. connector A can not be inserted into connector slot of B,C,D,E,F,J,K,I)

**STEP 2 ELECTRICAL**

This section considers the different drivers executions, illustrating the multiple variants of the available electrical connections. The electrical connections have to be wired according to the selected driver code

**WARNING:** remove power supply before any electrical or wiring operations

**WARNING:** a safety fuse is required in series to driver power supply - 2,5 A time lag fuse

**2.1 CONNECTORS**

Recommended LIYCY shielded cables: 0,5 mm<sup>2</sup> max 50 m - for logic - 1,5 mm<sup>2</sup> max 50 m - for power supply and solenoids

E-BM-TES/LES-N drivers without alternated P/Q control <b>SN</b>		E-BM-TES/LES-S drivers with alternated P/Q control ( <b>SP, SF, SL</b> software selectable)	
<b>A</b>	<b>Power supply</b>	<b>A</b>	<b>Power supply</b>
1	V+ (power supply 24Voc)	1	V+ (power supply 24Voc)
2	V0 (power supply 0Voc)	2	V0 (power supply 0Voc)
3	VL+ (power supply 24Voc)	3	VL+ (power supply 24Voc)
4	VLO (power supply 0Voc)	4	VLO (power supply 0Voc)
<b>B</b>	<b>Flow reference signal</b>	<b>B</b>	<b>Flow and pressure/force reference signals</b>
1	Q_INPUT+ (±10Voc / 4 ± 20mA)	1	Q_INPUT+ (±10Voc / 4 ± 20mA)
2	INPUT- (negative reference for Q_INPUT+)	2	INPUT- (negative reference for Q_INPUT+ and F_INPUT+)
3	NC	3	F_INPUT+ (±10Voc / 4 ± 20mA)
4	EARTH	4	EARTH
<b>C</b>	<b>Flow monitor, enable and fault signals</b>	<b>C</b>	<b>Flow and pressure/force monitor, enable and fault signals</b>
1	Q_MONITOR (±10Voc / 4 ± 20mA)	1	Q_MONITOR (±10Voc / 4 ± 20mA)
2	ENABLE (input 24Voc)	2	ENABLE (input 24Voc)
3	NC	3	F_MONITOR (±10Voc / 4 ± 20mA)
4	FAULT (output 24Voc)	4	FAULT (output 24Voc)
<b>D</b>	<b>LVDT position transducer - main stage valve</b>	<b>D</b>	<b>LVDT position transducer - main stage valve</b>
1	LVDT_L (main stage valve - transducer input signal)	1	LVDT_L (main stage valve - transducer input signal)
2	-15V (power supply -15Voc)	2	-15V (power supply -15Voc)
3	+15V (power supply +15Voc)	3	+15V (power supply +15Voc)
(1) 4	AGND (ground for transducer power and monitor)	(1) 4	AGND (ground for transducer power and monitor)
<b>E</b>	<b>LVDT position transducer - direct or pilot valve</b>	<b>E</b>	<b>LVDT position transducer - direct or pilot valve</b>
1	LVDT_T (direct or pilot valve - transducer input signal)	1	LVDT_T (direct or pilot valve - transducer input signal)
2	-15V (power supply -15Voc)	2	-15V (power supply -15Voc)
3	+15V (power supply +15Voc)	3	+15V (power supply +15Voc)
(2) 4	AGND (ground for transducer power and monitor)	(2) 4	AGND (ground for transducer power and monitor)
<b>F</b>	<b>Solenoids</b>	<b>F</b>	<b>Solenoids</b>
1	SOL_S1- (negative current to solenoid S1)	1	SOL_S1- (negative current to solenoid S1)
2	SOL_S1+ (positive current to solenoid S1)	2	SOL_S1+ (positive current to solenoid S1)
3	SOL_S2- (negative current to solenoid S2)	3	SOL_S2- (negative current to solenoid S2)
4	SOL_S2+ (positive current to solenoid S2)	4	SOL_S2+ (positive current to solenoid S2)
<b>I</b>	<b>Digital input</b>	<b>I</b>	<b>Digital input</b>
1	NC	1	NC
2	D_IN0 (input 24Voc) (5)	2	D_IN0 (input 24Voc) (5)
3	NC	3	NC
4	NC	4	NC
<b>J</b>	<b>Pressure/force transducer signal</b>	<b>J</b>	<b>Pressure/force transducer signal</b>
1	VF +24V (power supply 24Voc)	1	VF +24V (power supply 24Voc)
2	F_TR1 (±10Voc / 4 ± 20mA)	2	F_TR1 (±10Voc / 4 ± 20mA)
3	AGND	3	AGND
4	NC	4	NC
<b>K</b>	<b>Pressure transducer signal and digital input</b>	<b>K</b>	<b>Pressure transducer signal and digital input</b>
1	VF +24V (power supply 24Voc)	1	VF +24V (power supply 24Voc)
2	F_TR2 (±10Voc / 4 ± 20mA) (3)	2	F_TR2 (±10Voc / 4 ± 20mA) (3)
3	D_IN1 (input 24Voc) (4) (5)	3	D_IN1 (input 24Voc) (4) (5)
4	AGND	4	AGND
		5	NC

- (1) D connector is available only for TES-N versions 01HP / 05HP and LES-\*
- (2) E connector is available only for TES-\* versions 01H / 05H and LES-\*
- (3) Only for SF control
- (4) Only for SP or SL control
- (5) NP execution: multiple pressure/force PID selection - Fieldbus execution: general purpose digital input


**2.2 FIELDBUS CONNECTORS - only for BC, BP, EH, EW, EI, EP**

Select fieldbus connectors according to driver code and proceed with wirings operations


BC (DB9 - 9 pin)	BP (DB9 - 9 pin)	EH - EW - EI - EP (RJ45 - 8 pin)
2 CAN_L Bus line (low)	1 SHIELD	1 TX+ Transmitter
3 CAN_GND Signal zero data line	3 LINE-B Bus line (low)	2 RX- Receiver
5 CAN_SHLD Shield	5 DGND Data line - termination signal zero	3 TX- Transmitter
7 CAN_H Bus line (high)	6 +5V Termination supply signal	6 RX- Receiver
	8 LINE-A Bus line (high)	

**NOTE:** to interface BP execution with Siemens 6ES7972-0BA12-0XA connector, it is mandatory to use also one of the following adapters to avoid interference with the USB connector:  
DG909MF1 - the connector will be oriented upwards  
DG909MF3 - the connector will be oriented downwards


REFERENCE INPUT - VOLTAGE




REFERENCE INPUT - CURRENT




MONITOR OUTPUT - VOLTAGE




MONITOR OUTPUT - CURRENT




PRESSURE/FORCE TRANSDUCERS - only for S



LVDT TRANSDUCERS



SOLENOIDS



**WARNING:** for double solenoid valve pay attention to do not invert the connectors (1) and (2). If they are not inserted as shown in the example, the valve will not work properly and could cause eventual damages to the system.

STEP 3 SOFTWARE


**REMARK** off-board drivers are factory preset with default parameters, only few programming operations are mandatory for:  
• BC, BP, EH, EW, EI, EP setup the network parameters and the source of reference signals  
• SP, SF, SL setup the feedback's scale for remote transducers and the pressure/force PID parameters  
Driver programming can be performed through E-SW software or via fieldbus (not for NP)

PROGRAMMING					PC
3.1	3.2	3.3	3.4	3.5	3.6
CONNECTION	FIELDBUS	REFERENCES	P/Q SETUP	STORE	BACK UP

3.1 CONNECTION

- In order to access valve parameterization:  
• Install E-SW software on PC  
• Complete the electrical installation and power on the driver with 24Vdc

- Connect driver to the PC as shown below



**WARNING:** drivers USB port is not isolated!  
The use of USB isolator adapter is highly recommended for PC protection (see GS500)

- Launch the software using E-SW icon:  
• software does NOT detect valid connection communication is not established, please follow wizard procedure  
• software detects valid connection communication automatically established - driver is ON-LINE see 5

- Press buttons according the below sequence:

- a) ON-LINE - Recommended Wizard procedure for standard connection
- b) CONNECT TO NP, PS, IR, IL for driver without fieldbus communication
- c) CONNECT TO BC, BP, EH, EW, EI, EP for driver with fieldbus communication

- Communication established, driver is ON-LINE and it is possible change parameters

**NOTE:** for BC, BP, EH, EW, EI, EP please also refer to the following parameter settings:  
• see step 3.2 to change the network setup  
• see step 3.3 to change the reference signals setup

ON-LINE - Recommended Wizard procedure for standard connection via service port  
ON-LINE - Expert Manual procedure for connection via service port or via fieldbus port

NOTE: Bluetooth adapter available!  
For more info please refer to STARTUP BLUETOOTH guide

3.2 FIELDBUS - Network Management - only for BC, BP, EH, EW, EI, EP

Node, Station Alias, IP Address, Baudrate, etc... can be set through:

- Machine central unit (master) - please refer to E-MAN-S-\*\* fieldbus protocol programming manual

2) E-SW software

- switch to Level 2 - Advanced and browse to Network Management - Configuration to change below default settings:

<p><b>BC</b> CANopen Configuration file: EDS</p> <p>Configuration CANopen Node 1 Speed 50 Kbit/sec CANopen Hardware Filter Filter Active</p>	<p><b>BP</b> PROFIBUS DP Configuration file: GSD</p> <p>Defaults: Telegram 3 for SN Telegram 5 for SP, SF, SL</p>
<p><b>EH</b> EtherCAT Configuration file: XML</p> <p>Station Alias is assigned automatically by fieldbus master</p>	<p><b>EW</b> POWERLINK Configuration file: XDD</p>
<p><b>EI</b> EtherNet/IP Configuration file: EDS</p> <p>IP Address, Subnet Mask and Default Gateway are assigned by fieldbus master, IPConfig or BOOTP/DHCP utility</p>	<p><b>EP</b> PROFINET Configuration file: GSDML</p> <p>IP Address, Subnet Mask, Default Gateway and Station Name are assigned automatically by fieldbus master (e.g. Discovery and Configuration Protocol)</p>

- press Memory Store button and in Fieldbus Parameters press Store User button to save new setting into the driver (see 3.5)
- network configuration settings will be applied at next driver power-on or pressing the Restart button

**NOTE:** configuration files are available in USB memory stick of the software or in MyAtos area - [www.atos.com](http://www.atos.com)

3.3 REFERENCES - only for BC, BP, EH, EW, EI, EP

The source of reference signals for drivers with fieldbus:

- is preset as Analog by factory default
- can be managed through machine control unit by setting the source from Analog to Fieldbus

1 For SN, SP, SF, SL with fieldbus:  
• in Flow - Reference select Fieldbus

2 Only for SP, SF, SL with fieldbus:  
• in Pressure/Force - Reference select Fieldbus

3.4 P/Q SETUP - only for SP, SF, SL

The scaling procedure of the remote transducers feedbacks and pressure/force PID tuning are mandatory!  
Please refer to E-MAN-BM-LES-S operating manual.

**WARNING:** the system may be damaged and/or perform uncontrolled movements, due to vibrations and/or undesired transitions between controls P and Q or not executing at all the pressure/force limitation, if the operations listed in this paragraph are not performed.

3.5 STORE

Parameters modifications will be stored into driver permanent memory:

- press Memory Store button to access Driver - Memory Store window
- press Store User buttons to store Valve Parameters or Fieldbus Parameters

**WARNING:** During valve or fieldbus parameters storing operations, the driver automatically shuts down the solenoid power supply for a short time. Do not perform any storing commands while the system is working.

3.6 BACK UP

Parameter modifications will be saved into PC memory:

- press Save button to access Computer SW Archive - Setting Files page, Setting File Name pop-up appears
- input a valid name into Description field and press Ok button

HINT ! - Wizard objects dictionary - only for BC, BP, EH, EW, EI, EP

Press CTRL + H on the PC keyboard to open the context help form

Move arrow on parameter (e.g. Unit) to display the objects dictionary information to access the parameter via fieldbus

If present List, press [right arrow] to display values accepted by the parameter

Flow Reference Anal  
Unit: Voltage  
Type: Input  
Measure Actual Value: 0.0 %  
Priority: Manual  
Filter Time: 0.1 s  
Filter Frag: 1  
Filter Int: 1

Information  
Unit  
Standard Name: drv actual val cond unit  
Description: ValueFlowPosition = Ref. Analog range > Unit  
Index: 0x000 (11760)  
Sub Index: (void) [00]  
Type: INTEGERS  
Channel Selection: Index 0x0E01 - Sub Index 0x00 - Type UNSIGNED8 - Value 00

**NOTE:** alternatively right click on any parameter

TROUBLESHOOTING

Valve vibration or noise

- presence of air in the solenoid; perform air bleeding procedure – see tech. table of the connected valve

The valve does not follow the reference signal

- driver is powered off, verify presence of 24 Vdc power supply and the coil(s) connection
- driver is disabled, verify presence of 24 Vdc on enable pin
- flow/pressure values exceeding the valve's performance limits, verify that hydraulic operating conditions are in compliance with the valve's characteristics
- spool sticking, contact Atos service center
- missing piloting pressure, verify that hydraulic pressure in X (for DPZO/E and LIQZP) or P line (DPZO) is compliant with the required value
- wrong pilot/drain configuration - check if the pilot/drain configuration of the valve corresponds to the effective system layout

Software parameters modifications are lost when driver is switched off

- parameter store operation was not performed, check store procedure – see STEP 3, section 3.5

Software parameters modifications have no effect on the valve

- driver is OFF LINE, check connection procedure – see STEP 3, section 3.1

After the modifications of software parameters the valve does not work properly

- restore valve factory parameters using 'Restore Factory' button, located in 'Driver - Memory Store' window:  
- during restore, the current to the solenoid(s) will be temporarily switched to off!  
- factory parameters will be applied at next driver restart or after power off-on sequence!  
- perform the bias and scale configurations again!