

DIRECT OPERATED PROPORTIONAL DIRECTIONAL AND FLOW VALVES

Valve model:
DHZO-AES QVHZO-AES
DKZOR-AES QVKZOR-AES

Driver model:
E-RI-AES

IDENTIFICATION

Valve identification plates and label

Valve name plate : N

Driver label : L

1 : valve code
2 : valve matrix code
3 : hydraulic symbol

4 : driver code
5 : driver serial number
6 : factory firmware version

INSTALLATION TOOLS ACCORDING TO VALVE MODEL- not included

Fastening bolts	Wrenches	Main connectors		Fieldbus connectors			Transducer cable
		std./Q	/Z, /W	BC	BP	EH	/W
socket head screws	for fastening bolts and air bleeding	7 pin metallic	12 pin metallic	5 pin metallic	5 pin metallic	4 pin metallic	5 pin plastic
see STEP 1 and STEP 3		see STEP 2.1		see STEP 2.2			see STEP 2.3

PROGRAMMING TOOLS - not included

Software	USB connection KIT		OR	Bluetooth connection KIT	
	Cable	Isolator		Cable	Adapter
E-SW-* programming software	E-C-SB-USB/M12	E-A-SB-USB/OPT		E-C-SB-M12/BTH	E-A-SB-USB/BTH

PROGRAMMING SOFTWARE

The software is available in different versions according to the driver's options:

Software	supports	NP (USB)	IL (IO-Link)	PS (Serial)	IR (Infrared)
E-SW-BASIC	supports	BC (CANopen)	BP (PROFIBUS DP)	EH (EtherCAT)	EP (PROFINET RT/IRT)
E-SW-FIELDBUS	supports	EW (POWERLINK)	EI (EtherNet/IP)		
E-SW-/PQ	supports	valves with SP, SF, SL alternated P/Q control			

E-SW-FIELDBUS supports also valves without fieldbus communication; E-SW-/PQ supports also valves without P/Q control

REMARK Atos software is designed for Windows based operative systems - Windows XP SP3 or later

DOWNLOAD AREA

Perform the registration at www.atos.com/en-it/login by filling the form. In MyAtos area, perform login with personal username and password and then press the **Download area electronics** button

Free version of E-SW-BASIC can be downloaded and used by the "FREE Activation Code"

The software remains active for 10 days from the installation date and then it stops until the user inputs the Activation Code

RELATED DOCUMENTATION - www.atos.com - section Catalog on-line

FS900 Operating and maintenance information - tech. table	STARTUP E-SW-FIELDBUS Software startup guide
FS160 DHZO, DKZOR positive spool overlap - tech. table	STARTUP BLUETOOTH Bluetooth adapter startup guide
FS410 QVHZO, QVKZOR flow controls - tech. table	E-MAN-RI-AES AES - driver operating manual
P005 Mounting surface - tech. table	E-MAN-S-BC CANopen protocol programming manual
GS500 Programming tools - tech. table	E-MAN-S-BP PROFIBUS DP protocol programming manual
GS510 Fieldbus - tech. table	E-MAN-S-EH EtherCAT protocol programming manual
K800 Electric and electronic connectors - tech. table	

ATTENTION !

The purpose of this quickstart guide is show a logical sequence of basic operations. This guide does not cover all details or variants of Atos valves. All operations described in this document should be performed only by qualified personnel. Operations and images could be subject to change without notice. For further information please refer to related documentation.

CONTACT US

Atos spa - Italy - 21018 Sesto Calende www.atos.com support@atos.com

PRODUCTS OVERVIEW

EH
STEP 2.2
STEP 4
STEP 2.3

BP BC
STEP 2.2
STEP 2.3
STEP 4

STEP 1
STEP 3
STEP 2.1

INSTALLATION			PROGRAMMING
STEP 1	STEP 2	STEP 3	STEP 4
MECHANICAL	ELECTRICAL	HYDRAULICS	SOFTWARE

STEP 1 MECHANICAL

In case of first commissioning, before the valve installation the whole system must be correctly flushed to grant the required cleanliness level

During the flushing operation use on-off or by-pass valves in place of the proportional valve (do not remove connectors caps)

- remove protection pad **P1** located on the valve bottom face only immediately before installation
- check the presence and correct positioning of the seals on valve ports
- verify that valve mounting surface is clean and free from damages or burrs
- verify the correct valve orientation according to the pattern of the relevant mounting interface
- lock the fastening bolts respecting below sequence and tightening torque according to valve model

DHZO-AES	DKZOR-AES
<p>Mounting surface layout</p> <p>4401-03-02-0-05 4401-03-03-0-05 (for /Y without X port) Valve size ISO 4401: 06</p> <p>n°1 OR 2025 (for option /Y) n°4 OR 108</p> <p>Fastening bolts socket head screws Tightening torque: 8 Nm</p> <p>n°4 M5x50 class:12.9 wrench 4 mm</p>	<p>Mounting surface layout</p> <p>4401-05-04-0-05 4401-05-05-0-05 (for /Y without X port) Valve size ISO 4401: 10</p> <p>n°1 OR 108 (for option /Y) n°5 OR 2050</p> <p>Fastening bolts socket head screws Tightening torque: 15 Nm</p> <p>n°4 M6x40 class:12.9 wrench 5 mm</p>
QVHZO-AES	QVKZOR-AES
<p>Mounting surface layout</p> <p>4401-03-02-0-05 Valve size ISO 4401: 06</p> <p>n°4 OR 108</p> <p>Fastening bolts socket head screws Tightening torque: 8 Nm</p> <p>n°4 M5x50 class:12.9 wrench 4 mm</p>	<p>Mounting surface layout</p> <p>4401-05-04-0-05 Valve size ISO 4401: 10</p> <p>n°5 OR 2050</p> <p>Fastening bolts socket head screws Tightening torque: 15 Nm</p> <p>n°4 M6x40 class:12.9 wrench 5 mm</p>

STEP 2 ELECTRICAL

This section considers the different valves options, illustrating the multiple variants of the available electrical connections. The electrical connections have to be wired according to the selected valve code

2.1 MAIN CONNECTOR

1 Remove main connector cap **P2**

2 Select main connector according to valve code and proceed with wirings operations

3 Connect the valve to the system

ZM-7P - 7 pin MAIN CONNECTOR
ZM-12P - 12 pin MAIN CONNECTOR

WARNING: remove power supply before any electrical or wiring operations

WARNING: a safety fuse is required in series to driver power supply - 2.5 A time lag fuse

Standard		/Z and /W options	
A	V+ (power supply 24Vdc)	1	V+ (power supply 24Vdc)
B	V0 (power supply 0Vdc)	2	V0 (power supply 0Vdc)
C	AGND	3	ENABLE (input 24Vdc)
D	INPUT+ (±10Vdc / 4 ÷ 20mA)	4	INPUT+ (±10Vdc / 4 ÷ 20mA)
E	INPUT- (±10Vdc / 4 ÷ 20mA)	5	INPUT- (±10Vdc / 4 ÷ 20mA)
F	MONITOR (±5Vdc 1V=1A)	6	MONITOR (±5Vdc 1V=1A)
G	EARTH	7	NC
		8	NC for /Z option MONITOR2 (0 ÷ 5Vdc) for /W option
/Q option		9	VL+ (logic power supply 24Vdc)
A	V+ (power supply 24Vdc)	10	VL0 (logic power supply 0Vdc)
B	V0 (power supply 0Vdc)	11	FAULT (output 24Vdc)
C	ENABLE (input 24Vdc)	PE	EARTH
D	INPUT+ (±10Vdc / 4 ÷ 20mA)		
E	INPUT- (±10Vdc / 4 ÷ 20mA)		
F	MONITOR (±5Vdc 1V=1A)		
G	EARTH		

Recommended LIYCY shielded cables:
7 x 0,75 mm² max 20 m
7 x 1 mm² max 40 m

Recommended LIYCY shielded cable:
12 x 0,75 mm² max 20 m

2.2 FIELDBUS CONNECTORS

1 Remove fieldbus connectors caps **P3**

2 Select fieldbus connectors according to valve code and proceed with wirings operations

BC, BP
EH

M12 Coding A Cable diameter 6 ÷ 8 mm
M12 Coding B Cable diameter 6 ÷ 8 mm
M12 Coding D Cable diameter 4 ÷ 8 mm

BC	BP	EH
1 CAN_SHLD Shield	1 +5V Termination supply signal	1 TX+ Transmitter
2 not used	2 LINE-A Bus line (high)	2 RX- Receiver
3 CAN_GND Signal zero data line	3 DGND Data line - termination signal zero	3 TX- Transmitter
4 CAN_H Bus line (high)	4 LINE-B Bus line (low)	4 RX+ Receiver
5 CAN_L Bus line (low)	5 SHIELD	housing SHIELD

3 Connect the valve to the fieldbus network. For information about T connectors and fieldbus terminators see **GS500**

BC ZM-5PF - 5 pin
BP ZM-5PM/BP - 5 pin
EH ZM-4PM/E - 4 pin

NOTE: the use of above metallic connectors is strongly recommended in order to fulfill EMC requirements

2.3 REMOTE TRANSDUCER CONNECTOR - only for /W option

1 Remove transducer connector cap **P4**

2 Proceed with wirings operations

3 Connect the valve to the transducer

BC, BP
EH

ZH-5PM/1.5 - 1.5 m length
ZH-5PM/5 - 5 m length
5 pin plastic - single cable

EH
ZH-5PM/1.5 - 1.5 m length
ZH-5PM/5 - 5 m length
5 pin plastic - single cable


/W option

1	VF+ 24V (power supply 24Vdc)
2	TR1 (0 ÷ 10Vdc / 4 ÷ 20mA)
3	AGND
4	NC
5	NC


Recommended cable:
3 x 0,25 mm²

ELECTRICAL WIRING EXAMPLES


MAIN CONNECTOR - VOLTAGE




REFERENCE INPUT - COMMON MODE



MAIN CONNECTOR - MONITORS VOLTAGE ONLY



REMOTE TRANSDUCER - only for /W option



STEP 3 HYDRAULICS

Wrenches types

DHZO	DKZOR
3 mm	4 mm or 13 mm
Tightening torque 4 Nm	Tightening torque 8 Nm

Air bleeding:


- release 2 or 3 turns the air bleed screw **V**
- cycle the valve at low pressure until the oil leaking from the **V** port is exempted from air bubbles
- lock the air bleed screw **V**

NOTE: to facilitate bleeding operations, apply a light backpressure (1 or 2 bar) on T port by adding a check valve on T line
Consult tech table **FS900** for general guidelines about component's commissioning

HINT ! - Wizard objects dictionary - only for BC, BP, EH

Press **CTRL + H** on the PC keyboard to open the context help form
Move arrow on parameter (e.g. **Unit**) to display the objects dictionary information to access the parameter via fieldbus
If present **List**, press **→** to display values accepted by the parameter

NOTE: alternatively right click on any parameter



STEP 4 SOFTWARE

REMARK proportional valves with integral electronics are factory preset with default parameters, only few programming operations are mandatory for:

- setup the network parameters and the source of reference signals
- setup the feedback's scale for remote transducers only for /W option; please refer the E-MAN-RI-AES manual


Valve programming can be performed through E-SW software or via fieldbus

PROGRAMMING				PC
4.1	4.2	4.3	4.4	4.5
CONNECTION	FIELDBUS	REFERENCES	STORE	BACK UP

4.1 CONNECTION

- In order to access valve parameterization:
 - Install E-SW software on PC
 - Insert main connector to the valve and power on with 24Vdc

- Remove USB plastic protection cap **P5** and connect valve to the PC as shown below



WARNING: drivers USB port is not isolated!
The use of USB isolator adapter is highly recommended for PC protection (see **GS500**)

- Launch the software using E-SW icon:
 - software does **NOT** detect valid connection communication is not established, please follow wizard procedure
 - software detects valid connection communication automatically established - valve is **ON-LINE** see



- Press buttons according the below sequence:

- ON-LINE - Recommended**
Wizard procedure for standard connection
- CONNECT TO BC, BP, EH, EW, EI, EP**

NOTE: Bluetooth adapter available!
For more info please refer to **STARTUP BLUETOOTH** guide

REMARK: once removed the USB cable E-C-SB-USB/M12, screw the plastic protection cap **P5** applying the correct tightening torque, in order to preserve valve's IP protection characteristics

- Communication established, valve is **ON-LINE** and it is possible change parameters

Note: please also refer to the following parameter settings:

- see step 4.2 to change the network setup
- see step 4.3 to change the reference signals setup



4.2 FIELDBUS - Network Management

Node, Station Alias, IP Address, Baudrate, etc... can be set through:

- Machine central unit (master)** - please refer to E-MAN-S-** fieldbus protocol programming manual
- E-SW software**
 - switch to **Level 2 - Advanced** and browse to **Network Management - Configuration** to change below default settings:

BC CANopen Configuration file: EDS	BP PROFIBUS DP Configuration file: GSD Defaults: Telegram 3
EH EtherCAT Configuration file: XML	Station Alias is assigned automatically by fieldbus master

- press **Memory Store** button and in **Fieldbus Parameters** press **Store User** button to save new setting into the driver (see 4.4)
- network configuration settings will be applied at next driver power-on or pressing the **Restart** button

NOTE: configuration files are available in USB memory stick of the software or in MyAtos area - www.atos.com

4.3 REFERENCES

The source of reference signals for valves with fieldbus:

- is preset as **Analog** by factory default
- can be managed through machine control unit by setting the source from **Analog** to **Fieldbus**

In Valve - Reference select **Fieldbus**

4.4 STORE

Parameters modifications will be stored into driver permanent memory:

- press **Memory Store** button to access **Driver - Memory Store** window
- press **Store User** buttons to store **Valve Parameters** or **Fieldbus Parameters**

WARNING: During valve or fieldbus parameters storing operations, the driver automatically shuts down the solenoid power supply for a short time. Do not perform any storing commands while the system is working.

4.5 BACK UP

Parameter modifications will be saved into PC memory:

- press **Save** button to access **Computer SW Archive - Setting Files** page, **Setting File Name** pop-up appears
- input a valid name into **Description** field and press **Ok** button

TROUBLESHOOTING

Valve vibration or noise

- presence of air in the solenoid; perform air bleeding procedure - see STEP 3
- dither frequency too low; increase value of the frequency - please refer to E-MAN-RI-AES operating manual

The valve does not follow the reference signal

- valve is powered off, verify presence of 24 Vdc power supply
- valve is disabled, verify presence of 24 Vdc on enable pin - only for /Q, /Z and /W options
- flow/pressure values exceeding the valve's performance limits, verify that hydraulic operating conditions are in compliance with the valve's characteristics
- big hysteresis or spool stick-slip, reduce the dither frequency
- spool sticking, contact Atos service center

Software parameters modifications are lost when valve is switched off

- parameter store operation was not performed, check store procedure - see STEP 4, section 4.4

Software parameters modifications have no effect on the valve

- valve is OFF LINE, check connection procedure - see STEP 4, section 4.1

After the modifications of software parameters the valve does not work properly

- restore valve factory parameters using 'Restore Factory' button, located in 'Driver - Memory Store' window:
 - during restore, the current to the solenoid(s) will be temporarily switched to off!
 - factory parameters will be applied at next driver restart or after power off-on sequence!