

PILOTTED OPERATED PROPORTIONAL DIRECTIONAL VALVES

Valve model:	DPZO-LES-1	DPZO-LES-4M	DPZO-LES-2	DPZO-LES-6	DPZO-LES-4	DPZO-LES-8	Valve model:	DPZO-TES-1	DPZO-TES-4M	DPZO-TES-2	DPZO-TES-6	DPZO-TES-4
Driver models:	E-RI-LES/TES-N for piloted valves without alternated P/Q control SN E-RI-LES/TES-S for piloted valves with alternated P/Q control SP, SF, SL											

IDENTIFICATION

Valve identification plates and label

Valve name plate : M
1 : valve code
2 : valve matrix code
3 : valve hydraulic symbol

Pilot valve name plate : N
4 : pilot valve code
5 : pilot valve matrix code
6 : pilot hydraulic symbol

Driver label : L
7 : driver code
8 : driver serial number
9 : factory firmware version

INSTALLATION TOOLS ACCORDING TO VALVE MODEL- not included

Fastening bolts	Wrenches	Main connectors	Fieldbus connectors	Transducers cables
socket head screws see STEP 1 and STEP 3	for fastening bolts and air bleeding	SN, SP, SF, SL 7 pin metallic 12 pin metallic see STEP 2.1	BC, BP, EH, EW, EI, EP 5 pin metallic 4 pin metallic see STEP 2.2	SP, SL, SF 5 pin plastic 5 pin plastic see STEP 2.3

PROGRAMMING TOOLS - not included

Software	USB connection KIT	OR	Bluetooth connection KIT
E-SW-* programming software	Cable E-C-SB-USB/M12 Isolator E-A-SB-USB/OPT		Cable E-C-SB-M12/BTH Adapter E-A-SB-USB/BTH

PROGRAMMING SOFTWARE

The software is available in different versions according to the driver's options:

E-SW-BASIC supports	NP (USB)	IL (IO-Link)	PS (Serial)	IR (Infrared)
E-SW-FIELDBUS supports	BC (CANopen)	BP (PROFIBUS DP)	EH (EtherCAT)	EW (POWERLINK)
E-SW-/PQ supports	valves with SP, SF, SL alternated P/Q control	EI (EtherNet/IP)	EP (PROFINET RT/IRT)	

E-SW-FIELDBUS supports also valves without fieldbus communication; E-SW-/PQ supports also valves without P/Q control

REMARK Atos software is designed for Windows based operative systems - Windows XP SP3 or later

DOWNLOAD AREA

Perform the registration at www.atos.com/en-it/login by filling the form. In MyAtos area, perform login with personal username and password and then press the **Download area electronics** button

Free version of E-SW-BASIC can be downloaded and used by the "FREE Activation Code"

The software remains active for 10 days from the installation date and then it stops until the user inputs the Activation Code

RELATED DOCUMENTATION - www.atos.com - section Catalog on-line

FS900 Operating and maintenance information - tech. table	STARTUP E-SW-BASIC Software startup guide
FS500 Digital proportional valves with P/Q - tech. table	STARTUP E-SW-FIELDBUS Software startup guide
FS172 DPZO one LVDT positive spool overlap - tech. table	STARTUP BLUETOOTH Bluetooth adapter startup guide
FS175 DPZO two LVDT positive spool overlap - tech. table	E-MAN-RI-LES TES/LES - driver operating manual
FS178 DPZO two LVDT zero spool overlap - tech. table	E-MAN-RI-LES-S TES/LES - driver with S option operating manual
P005 Mounting surface - tech. table	E-MAN-S-BC CANopen protocol programming manual
GS500 Programming tools - tech. table	E-MAN-S-BP PROFIBUS DP protocol programming manual
GS510 Fieldbus - tech. table	E-MAN-S-EH EtherCAT protocol programming manual
K800 Electric and electronic connectors - tech. table	E-MAN-S-EW POWERLINK protocol programming manual
	E-MAN-S-EI EtherNet/IP protocol programming manual
	E-MAN-S-EP PROFINET protocol programming manual

ATTENTION!
The purpose of this quickstart guide is show a logical sequence of basic operations. This guide does not cover all details or variants of Atos valves. All operations described in this document should be performed only by qualified personnel. Operations and images could be subject to change without notice. For further information please refer to related documentation.

PRODUCTS OVERVIEW

INSTALLATION			PROGRAMMING
STEP 1	STEP 2	STEP 3	STEP 4
MECHANICAL	ELECTRICAL	HYDRAULICS	SOFTWARE

STEP 1 MECHANICAL

In case of first commissioning, before the valve installation the whole system must be correctly flushed to grant the required cleanliness level
During the flushing operation use on-off or by-pass valves in place of the proportional valve

- remove protection pad **P1** located on the valve bottom face only immediately before installation (do not remove connectors caps)
- check the presence and correct positioning of the seals on valve ports
- verify that valve mounting surface is clean and free from damages or burrs
- verify the correct valve orientation according to the pattern of the relevant mounting interface
- lock the fastening bolts respecting below sequence and tightening torque according to valve model

<p>DPZO-LES*-1 DPZO-TES*-1</p> <p>Mounting surface layout</p> <p>4401-05-05-0-05 Valve size ISO 4401: 10</p> <p>Fastening bolts socket head screws Tightening torque: 15 Nm</p> <p>n°4 M6x40 class:12.9 wrench 5 mm</p>	<p>DPZO-LES*-2 DPZO-TES*-2</p> <p>Mounting surface layout</p> <p>4401-07-07-0-05 Valve size ISO 4401: 16</p> <p>Fastening bolts socket head screws Tightening torque: 15 Nm for M6, 70 Nm for M10</p> <p>n°4 M10x45 class:12.9 wrench 8 mm</p>
<p>DPZO-LES*-4 DPZO-TES*-4</p> <p>Mounting surface layout</p> <p>4401-08-08-0-05 Valve size ISO 4401: 25</p> <p>Fastening bolts socket head screws Tightening torque: 125 Nm</p> <p>n°6 M12x60 class:12.9 wrench 10 mm</p>	<p>DPZO-LES*-4M DPZO-TES*-4M</p> <p>Mounting surface layout</p> <p>4401-08-08-0-05 Valve size ISO 4401: 27</p> <p>Fastening bolts socket head screws Tightening torque: 125 Nm</p> <p>n°6 M12x60 class:12.9 wrench 10 mm</p>
<p>DPZO-LES*-6 DPZO-TES*-6</p> <p>Mounting surface layout</p> <p>4401-10-09-0-05 Valve size ISO 4401: 32</p> <p>Fastening bolts socket head screws Tightening torque: 600 Nm</p> <p>n°6 M20x90 class:12.9 wrench 17 mm</p>	<p>DPZO-LES*-8</p> <p>Mounting surface layout</p> <p>4401-10-09-0-05 Valve size ISO 4401: 35</p> <p>Fastening bolts socket head screws Tightening torque: 600 Nm</p> <p>n°6 M20x100 class:12.9 wrench 17 mm</p>

STEP 2 ELECTRICAL

This section considers the different valves options, illustrating the multiple variants of the available electrical connections. The electrical connections have to be wired according to the selected valve code

WARNING: for electrical connections of safety proportional valves please refer to technical tables:
FY100 safety proportionals /U with double power supply - **FY200** safety proportionals /K with on-off signals

2.1 MAIN CONNECTOR

- Remove main connector cap **P2**
- Select main connector according to valve code and proceed with wirings operations
- Connect the valve to the system

WARNING: remove power supply before any electrical or wiring operations

NOTE: the use of above metallic connectors is strongly recommended in order to fulfill EMC requirements

WARNING: a safety fuse is required in series to driver power supply - 2,5 A time lag fuse

SN standard		SN /Z option	
A	V+ (power supply 24Vdc)	1	V+ (power supply 24Vdc)
B	V0 (power supply 0Vdc)	2	V0 (power supply 0Vdc)
C	AGND (input 24Vdc)	3	ENABLE (input 24Vdc)
D	Q_INPUT+ (±10Vdc / 4 + 20mA)	4	Q_INPUT+ (±10Vdc / 4 + 20mA)
E	Q_INPUT- (±10Vdc / 4 + 20mA)	5	INPUT- (±10Vdc / 4 + 20mA)
F	Q_MONITOR (±10Vdc / 4 + 20mA)	6	Q_MONITOR (±10Vdc / 4 + 20mA)
G	EARTH	7	NC
		8	NC
		9	VL+ (power supply 24Vdc)
		10	V0 (power supply 0Vdc)
		11	FAULT (output 24Vdc)
		PE	EARTH

SN /Q option		SP, SF, SL standard	
A	V+ (power supply 24Vdc)	1	V+ (power supply 24Vdc)
B	V0 (power supply 0Vdc)	2	V0 (power supply 0Vdc)
C	AGND (input 24Vdc)	3	ENABLE (input 24Vdc)
D	Q_INPUT+ (±10Vdc / 4 + 20mA)	4	Q_INPUT+ (±10Vdc / 4 + 20mA)
E	Q_INPUT- (±10Vdc / 4 + 20mA)	5	INPUT- (±10Vdc / 4 + 20mA)
F	Q_MONITOR (±10Vdc / 4 + 20mA)	6	Q_MONITOR (±10Vdc / 4 + 20mA)
G	EARTH	7	VL+ (power supply 24Vdc)
		8	F_MONITOR (±10Vdc / 4 + 20mA)
		9	ENABLE (input 24Vdc)
		10	F_MONITOR (±10Vdc / 4 + 20mA)
		11	FAULT (output 24Vdc)
		PE	EARTH

2.2 FIELDBUS CONNECTORS - only for BC, BP, EH, EW, EI, EP

- Remove fieldbus connectors caps **P3**
- Select fieldbus connectors according to valve code and proceed with wirings operations
- Connect the valve to the fieldbus network. For information about fieldbus terminators see GS500. The use of above metallic connectors is strongly recommended in order to fulfill EMC requirements.

BC		BP		EH - EW - EI - EP	
1	CAN_SHLD Shield	1	+5V Termination supply signal	1	TX+ Transmitter
2	not used	2	LINE-A Bus line (high)	2	RX- Receiver
3	CAN_GND Signal zero data line	3	DGND Data line - termination signal zero	3	TX- Transmitter
4	CAN_H Bus line (high)	4	LINE-B Bus line (low)	4	RX+ Receiver
5	CAN_L Bus line (low)	5	SHIELD	housing	SHIELD

2.3 REMOTE TRANSDUCERS CONNECTOR - only for SP, SF, SL

- Remove transducer connector cap **P4**
- Select transducer(s) connection and proceed with wirings operations
- Connect the valve to the transducer(s)

Recommended cable:

SP, SL - Single Transducer	
1	VF+ 24V (power supply 24Vdc)
2	TR1 (0 ± 10Vdc / 4 + 20mA)
3	AGND
4	NC
5	NC


SF - Double Transducers	
1	VF+ 24V (power supply 24Vdc)
2	TR1 (0 ± 10Vdc / 4 + 20mA)
3	AGND
4	TR2 (0 ± 10Vdc / 4 + 20mA)
5	NC

ZH-5PM/1.5 - 1.5 m length
ZH-5PM/5 - 5 m length
5 pin plastic - single cable


ZH-5PM-2/2 - 2 m length
4 pin - plastic - double cable

ELECTRICAL WIRING EXAMPLES


MAIN CONNECTOR - VOLTAGE




MAIN CONNECTOR - CURRENT




REFERENCE INPUT - COMMON MODE




REFERENCE INPUT - COMMON MODE




MONITOR OUTPUT




MONITOR OUTPUT




REMOTE TRANSDUCER - only for SP, SL



REMOTE TRANSDUCERS - only for SF



STEP 3 HYDRAULICS



Wrench type
3 mm

Tightening torque
4 Nm

Air bleeding:

- release 2 or 3 turns the air bleed screw **V**
- cycle the valve at low pressure until the oil leaking from the **V** port is exempted from air bubbles
- lock the air bleed screw **V**

NOTE: to facilitate bleeding operations, apply a light backpressure (1 or 2 bar) by adding a check valve on Y line

Consult tech table **FS900** for general guidelines about component's commissioning


WARNING: To avoid overheating and possible damage of the electronic driver, the valves must be never energized without hydraulic supply to the pilot stage. In case of prolonged pauses of the valve operation during the machine cycle, it is always advisable to switch off or disable the driver (option /Q or /Z)

HINT ! - Wizard objects dictionary - only for BC, BP, EH, EW, EI, EP

Press **CTRL + H** on the PC keyboard to open the context help form

Move arrow on parameter (e.g. **Unit**) to display the objects dictionary information to access the parameter via fieldbus

If present **List**, press **→** to display values accepted by the parameter



NOTE: alternatively right click on any parameter

STEP 4 SOFTWARE

REMARK proportional valves with integral electronics are factory preset with default parameters, only few programming operations are mandatory for:


- BC, BP, EH, EW, EI, EP** setup the network parameters and the source of reference signals
- SP, SF, SL** setup the feedback's scale for remote transducers and the pressure/force PID parameters

Valve programming can be performed through E-SW software or via fieldbus (not for NP)

PROGRAMMING						PC
4.1	4.2	4.3	4.4	4.5	4.6	4.7
CONNECTION	FIELDBUS	REFERENCES	P/Q SETUP	SMART TUNING	STORE	BACK UP


4.1 CONNECTION

- In order to access valve parameterization:
 - Install E-SW software on PC
 - Insert main connector to the valve and power on with 24Vdc
- Remove USB plastic protection cap **P5** and connect valve to the PC as shown below



- Launch the software using E-SW icon:
 - software does NOT detect valid connection communication is not established, please follow wizard procedure
 - software detects valid connection communication automatically established - valve is **ON-LINE** see 5

- Press buttons according the below sequence:
 - a) ON-LINE - Recommended** Wizard procedure for standard connection
 - b) CONNECT TO NP, PS, IR, IL** for valve without fieldbus communication
 - c) CONNECT TO BC, BP, EH, EW, EI, EP** for valve with fieldbus communication
- Communication established, valve is **ON-LINE** and it is possible change parameters



NOTE: Bluetooth adapter available! For more info please refer to **STARTUP BLUETOOTH** guide

REMARK: once removed the USB cable E-C-SB-USB/M12, screw the plastic protection cap **P5** applying the correct tightening torque, in order to preserve valve's IP protection characteristics

4.2 FIELDBUS - Network Management - only for BC, BP, EH, EW, EI, EP

Node, Station Alias, IP Address, Baudrate, etc... can be set through:

- Machine central unit (master)** - please refer to E-MAN-S-** fieldbus protocol programming manual
- E-SW software**
 - switch to **Level 2 - Advanced** and browse to **Network Management - Configuration** to change below default settings:


BC CANopen Configuration file: EDS Configuration CANopen Node: 1 Speed: 50 Kbit/sec Filter Active	BP PROFIBUS DP Configuration file: GSD Defaults: Telegram 3 for SN, Telegram 5 for SP, SF, SL
EH EtherCAT Configuration file: XML Station Alias is assigned automatically by fieldbus master	EW POWERLINK Configuration file: XDD
EI EtherNet/IP Configuration file: EDS IP Address, Subnet Mask and Default Gateway are assigned by fieldbus master, IPConfig or BOOTP/DHCP utility	EP PROFINET Configuration file: GSDML IP Address, Subnet Mask, Default Gateway and Station Name are assigned automatically by fieldbus master (e.g. Discovery and Configuration Protocol)

- press **Memory Store** button and in **Fieldbus Parameters** press **Store User** button to save new setting into the driver (see 4.6)
 - network configuration settings will be applied at next driver power-on or pressing the **Restart** button
- NOTE:** configuration files are available in USB memory stick of the software or in MyAtos area - www.atos.com

4.3 REFERENCES - only for BC, BP, EH, EW, EI, EP

The source of reference signals for valves with fieldbus:

- is preset as **Analog** by factory default
- can be managed through machine control unit by setting the source from **Analog to Fieldbus**




4.4 P/Q SETUP - only for SP, SF, SL

The scaling procedure of the remote transducers feedbacks and pressure/force PID tuning are mandatory! Please refer to E-MAN-RI-LES-S operating manual.

WARNING: the system may be damaged and/or perform uncontrolled movements, due to vibrations and/or undesired transitions between controls P and Q or not executing at all the pressure/force limitation, if the operations listed in this paragraph are not performed.

4.5 SMART TUNING - E-SW level 2 functionality

Smart tuning allows to adjust the valve dynamic response in order to match different performance requirements.



4.6 STORE

- Parameters modifications will be stored into driver permanent memory:
- press **Memory Store** button to access **Driver - Memory Store** window
 - press **Store User** buttons to store **Valve Parameters** or **Fieldbus Parameters**

WARNING: During valve or fieldbus parameters storing operations, the driver automatically shuts down the solenoid power supply for a short time. Do not perform any storing commands while the system is working.

4.7 BACK UP

- Parameter modifications will be saved into PC memory:
- press **Save** button to access **Computer SW Archive - Setting Files** page, **Setting File Name** pop-up appears
 - input a valid name into **Description** field and press **Ok** button

TROUBLESHOOTING

- Valve vibration or noise**
- presence of air in the solenoid; perform air bleeding procedure - see STEP 3
- The valve does not follow the reference signal**
- valve is powered off, verify presence of 24 Vdc power supply
 - valve is disabled, verify presence of 24 Vdc on enable pin - only for /Q and /Z options
 - flow/pressure values exceeding the valve's performance limits, verify that hydraulic operating conditions are in compliance with the valve's characteristics
 - spool sticking, contact Atos service center
 - missing piloting pressure, verify that hydraulic power level is compliant with valve's characteristics
 - wrong pilot/drain configuration - check if the pilot/drain configuration of the valve corresponds to the effective system layout
- Software parameters modifications are lost when valve is switched off**
- parameter store operation was not performed, check store procedure - see STEP 4, section 4.6
- Software parameters modifications have no effect on the valve**
- valve is OFF LINE, check connection procedure - see STEP 4, section 4.1
- After the modifications of software parameters the valve does not work properly**
- restore valve factory parameters using 'Restore Factory' button, located in 'Driver - Memory Store' window:
 - during restore, the current to the solenoid(s) will be temporarily switched to off!
 - factory parameters will be applied at next driver restart or after power off-on sequence!