

**PROPORTIONAL AND SERVOPROPORTIONAL CARTRIDGES**

Valve model: LIQZP-LES 2 or 3 way Valve model: LIQZP-TES 2 way

Driver models: E-RI-LES/TES-N for valves without alternated P/Q control SN E-RI-LES/TES-S for valves with alternated P/Q control SP, SL

**IDENTIFICATION**

Valve identification plates and label

Cartridge name plate : M Pilot valve name plate : N Driver label : L

1 : cartridge code  
2 : pilot valve code  
3 : pilot valve matrix code  
4 : pilot hydraulic symbol  
5 : driver code  
6 : driver serial number  
7 : factory firmware version

**INSTALLATION TOOLS ACCORDING TO VALVE MODEL- not included**

Fastening bolts	Wrenches	Main connectors	Fieldbus connectors	Transducers cables
socket head screws	for fastening bolts and air bleeding	SN, SN,SP,SL	BC,BP, EH,EW,EI,EP	SP,SL
see STEP 1 and STEP 3		7 pin metallic, 12 pin metallic	5 pin metallic, 4 pin metallic	5 pin plastic
		see STEP 2.1	see STEP 2.2	see STEP 2.3

**PROGRAMMING TOOLS - not included**

Software	USB connection KIT	OR	Bluetooth connection KIT
E-SW-* programming software	Cable, Isolator		Cable, Adapter
	E-C-SB-USB/M12, E-A-SB-USB/OPT		E-C-SB-M12/BTH, E-A-SB-USB/BTH

**PROGRAMMING SOFTWARE**

The software is available in different versions according to the driver's options:

Software	supports	NP (USB)	IL (IO-Link)	PS (Serial)	IR (Infrared)
E-SW-BASIC					
E-SW-FIELDBUS		BC (CANopen), EW (POWERLINK)	BP (PROFIBUS DP), EI (EtherNet/IP)	EH (EtherCAT), EP (PROFINET RT/IRT)	
E-SW-/PQ		valves with SP, SF, SL alternated P/Q control			

E-SW-FIELDBUS supports also valves without fieldbus communication; E-SW-/PQ supports also valves without P/Q control

REMARK Atos software is designed for Windows based operative systems - Windows XP SP3 or later

**DOWNLOAD AREA**

Perform the registration at [www.atos.com/en-it/login](http://www.atos.com/en-it/login) by filling the form. In MyAtos area, perform login with personal username and password and then press the **Download area electronics** button

Free version of E-SW-BASIC can be downloaded and used by the "FREE Activation Code"

The software remains active for 10 days from the installation date and then it stops until the user inputs the Activation Code

**RELATED DOCUMENTATION - www.atos.com - section Catalog on-line**

FS900 Operating and maintenance information - tech. table	STARTUP E-SW-BASIC Software startup guide
FS500 Digital proportional valves with P/Q - tech. table	STARTUP E-SW-FIELDBUS Software startup guide
FS330 LIQZP 2-way cartridges, high performance - tech. table	STARTUP BLUETOOTH Bluetooth adapter startup guide
FS340 LIQZP 3-way cartridges - tech. table	E-MAN-RI-LES TES/LES - driver operating manual
P006 Mounting surfaces - tech. table	E-MAN-RI-LES-S TES/LES - driver with S option operating manual
GS500 Programming tools - tech. table	E-MAN-S-BC CANopen protocol programming manual
GS510 Fieldbus - tech. table	E-MAN-S-BP PROFIBUS DP protocol programming manual
K800 Electric and electronic connectors - tech. table	E-MAN-S-EH EtherCAT protocol programming manual
	E-MAN-S-EW POWERLINK protocol programming manual
	E-MAN-S-EI EtherNet/IP protocol programming manual
	E-MAN-S-EP PROFINET protocol programming manual


**ATTENTION !**

The purpose of this quickstart guide is show a logical sequence of basic operations. This guide does not cover all details or variants of Atos valves. All operations described in this document should be performed only by qualified personnel. Operations and images could be subject to change without notice. For further information please refer to related documentation.

**CONTACT US**

Atos spa - Italy - 21018 Sesto Calende [www.atos.com](http://www.atos.com) [support@atos.com](mailto:support@atos.com)

**PRODUCTS OVERVIEW**




INSTALLATION			PROGRAMMING
STEP 1	STEP 2	STEP 3	STEP 4
MECHANICAL	ELECTRICAL	HYDRAULICS	SOFTWARE

**STEP 1 MECHANICAL**

In case of first commissioning, before the valve installation the whole system must be correctly flushed to grant the required cleanliness level:

- remove the cartridge protection (do not remove connectors caps)
- check the presence and correct positioning of the seals on the mounting surface ports ( X - Y ) and on the cartridge ( K )



- verify that valve mounting surface and the manifold cavity are clean and free from damages or burrs
- verify the correct valve orientation according to the pattern of the relevant mounting interface
- lock the fastening bolts respecting tightening torque according to valve model

**SIZE 16 to 63**  
mounting surface layout ISO 7368

LIQZP

locating pin size 125

locating pin size 80 ÷ 100

n°2 OR

n°4 fastening bolt (supplied with the valve)

**SIZE 80 to 125**  
mounting surface layout ISO 7368

LIQZP

locating pin size 125

locating pin size 80 ÷ 100

n°2 OR

n°8 fastening bolt (supplied with the valve)

Notes: ISO 7368 cavity only for 2 way version

Type	Size	Fastening Bolt class: 12.9	Wrench (mm)	Tightening Torque (Nm)	O-Ring (X - Y)
LIQZP	16	n°4 M8 x 90	6	35	n°2 OR-108
	25	n°4 M12 x 100	10	125	n°2 OR-108
	32	n°4 M16 x 60	14	300	n°2 OR-2043
	40	n°4 M20 x 70	17	600	n°2 OR-2050
	50	n°4 M20 x 80	17	600	n°2 OR-3043
	63	n°4 M30 x 120	22	2100	n°2 OR-3050
	80	n°8 M24 x 80	19	1000	n°2 OR-4075
	100	n°8 M30 x 120	22	2100	n°2 OR-4087
	125	n°8 M36 x 260	27	3600	n°2 OR-37x5

**STEP 2 ELECTRICAL**

This section considers the different valves options, illustrating the multiple variants of the available electrical connections. The electrical connections have to be wired according to the selected valve code

**2.1 MAIN CONNECTOR**

**1** Remove main connector cap P2

**2** Select main connector according to valve code and proceed with wirings operations

**WARNING:** remove power supply before any electrical or wiring operations

Recommended LIQCY shielded cables:  
7 x 0,75 mm<sup>2</sup> max 20 m  
7 x 1 mm<sup>2</sup> max 40 m

Recommended LIQCY shielded cable:  
12 x 0,75 mm<sup>2</sup> max 20 m

**3** Connect the valve to the system

ZM-7P - 7 pin MAIN CONNECTOR

ZM-12P - 12 pin MAIN CONNECTOR

NOTE: the use of above metallic connectors is strongly recommended in order to fulfill EMC requirements

**WARNING:** a safety fuse is required in series to driver power supply - 2,5 A time lag fuse

SN standard		SN /Z option	
A	V+ (power supply 24Voc)	1	V+ (power supply 24Voc)
B	V0 (power supply 0Voc)	2	V0 (power supply 0Voc)
C	AGND (input 24Voc)	3	ENABLE (input 24Voc)
D	Q_INPUT+ (±10Voc / 4 ÷ 20mA)	4	Q_INPUT+ (±10Voc / 4 ÷ 20mA)
E	INPUT- (input 24Voc)	5	INPUT- (±10Voc / 4 ÷ 20mA)
F	Q_MONITOR (±10Voc / 4 ÷ 20mA)	6	Q_MONITOR (±10Voc / 4 ÷ 20mA)
G	EARTH	7	NC
		8	NC
		9	VL+ (power supply 24Voc)
		10	VL0 (power supply 0Voc)
		11	FAULT (output 24Voc)
		PE	EARTH

SN /Q option		SN /F option	
A	V+ (power supply 24Voc)	A	V+ (power supply 24Voc)
B	V0 (power supply 0Voc)	B	V0 (power supply 0Voc)
C	ENABLE (input 24Voc)	C	AGND
D	Q_INPUT+ (±10Voc / 4 ÷ 20mA)	D	Q_INPUT+ (±10Voc / 4 ÷ 20mA)
E	INPUT- (input 24Voc)	E	INPUT- (±10Voc / 4 ÷ 20mA)
F	Q_MONITOR (±10Voc / 4 ÷ 20mA)	F	FAULT (output 24Voc)
G	EARTH	G	EARTH

SP, SL standard	
1	V+ (power supply 24Voc)
2	V0 (power supply 0Voc)
3	ENABLE (input 24Voc)
4	Q_INPUT+ (±10Voc / 4 ÷ 20mA)
5	INPUT- (input 24Voc)
6	Q_MONITOR (±10Voc / 4 ÷ 20mA)
7	F_INPUT+ (±10Voc / 4 ÷ 20mA)
8	F_MONITOR (±10Voc / 4 ÷ 20mA)
9	VL+ (power supply 24Voc - fieldbus)
10	VL0 (power supply 0Voc - fieldbus)
11	FAULT (output 24Voc)
PE	EARTH

**2.2 FIELDBUS CONNECTORS - only for BC, BP, EH, EW, EI, EP**

**1** Remove fieldbus connectors caps P3

**2** Select fieldbus connectors according to valve code and proceed with wirings operations

M12 Coding A Cable diameter 6 ÷ 8 mm

M12 Coding B Cable diameter 6 ÷ 8 mm

M12 Coding D Cable diameter 4 ÷ 8 mm

BC		BP		EH - EW - EI - EP	
1	CAN_SHLD Shield	1	+5V Termination supply signal	1	TX+ Transmitter
2	not used	2	LINE-A Bus line (high)	2	RX- Receiver
3	CAN_GND Signal zero data line	3	DGND Data line - termination signal zero	3	TX- Transmitter
4	CAN_H Bus line (high)	4	LINE-B Bus line (low)	4	RX+ Receiver
5	CAN_L Bus line (low)	5	SHIELD	housing	SHIELD

**3** Connect the valve to the fieldbus network. For information about fieldbus terminators see GS500

BC: ZM-5PF - 5 pin, ZM-5PM - 5 pin

BP: ZM-5PF/BP - 5 pin, ZM-5PM/BP - 5 pin

EH, EW, EI, EP: ZM-4PME - 4 pin, ZM-4PME - 4 pin

**2.3 REMOTE TRANSDUCER CONNECTOR - only for SP, SL**

**1** Remove transducer connector cap P4

**2** Proceed with wirings operations

**3** Connect the valve to the transducer

Recommended cable: 3 x 0,25 mm<sup>2</sup>


SP, SL - Single Transducer

1	VF+ 24V (power supply 24Voc)
2	TR1 (0 ÷ 10Voc / 4 ÷ 20mA)
3	AGND
4	NC
5	NC


ZH-5PM/1.5 - 1.5 m length  
ZH-5PM/5 - 5 m length  
5 pin plastic - single cable

**ELECTRICAL WIRING EXAMPLES**


**MAIN CONNECTOR - VOLTAGE**




**MAIN CONNECTOR - CURRENT**




**REFERENCE INPUT - COMMON MODE**




**REFERENCE INPUT - COMMON MODE**




**MONITOR OUTPUT**




**MONITOR OUTPUT**




**REMOTE TRANSDUCER - only for SP, SL**



**STEP 3 HYDRAULICS**



**Main stage air bleeding - only LES:**  
 • at the machine commissioning it is advisable to bleed the air from spool piloting chambers, by loosening the **MA** and **MB** plugs




**Pilot air bleeding:**  
 • release 2 or 3 turns the air bleed screw **V**  
 • cycle the valve at low pressure until the oil leaking from the **V** port is exempted from air bubbles  
 • lock the air bleed screw **V**  
**NOTE:** to facilitate bleeding operations, apply a light backpressure (1 or 2 bar) by adding a check valve on Y line. The check valve is particularly suggested for valves size 63 to 125 installed with the solenoid upward  
 Consult **FS900** for general guidelines about component's commissioning

**WARNING:** To avoid overheating and possible damage of the electronic driver, the valves must be never energized without hydraulic supply to the pilot stage. In case of prolonged pauses of the valve operation during the machine cycle, it is always advisable to switch off or disable the driver (option /Q or /Z)

**HINT ! - Wizard objects dictionary - only for BC, BP, EH, EW, EI, EP**

Press **CTRL + H** on the PC keyboard to open the context help form  
 Move arrow on parameter (e.g. **Unit**) to display the objects dictionary information to access the parameter via fieldbus  
 If present **List**, press **→** to display values accepted by the parameter



**NOTE:** alternatively right click on any parameter


**STEP 4 SOFTWARE**

**REMARK** proportional valves with integral electronics are factory preset with default parameters, only few programming operations are mandatory for:  
 • **BC, BP, EH, EW, EI, EP** setup the network parameters and the source of reference signals  
 • **SP, SF, SL** setup the feedback's scale for remote transducers and the pressure/force PID parameters  
 Valve programming can be performed through E-SW software or via fieldbus (not for NP)

PROGRAMMING						PC
4.1	4.2	4.3	4.4	4.5	4.6	4.7
CONNECTION	FIELDBUS	REFERENCES	P/Q SETUP	SMART TUNING	STORE	BACK UP


**4.1 CONNECTION**

- In order to access valve parameterization:  
 • Install E-SW software on PC  
 • Insert main connector to the valve and power on with 24Vdc
- Remove USB plastic protection cap **P5** and connect valve to the PC as shown below



- Launch the software using E-SW icon:  
 • **software does NOT detect valid connection** communication is not established, please follow wizard procedure  
 • **software detects valid connection** communication automatically established - valve is **ON-LINE** see 5

- Press buttons according the below sequence:  
 a) **ON-LINE - Recommended** Wizard procedure for standard connection  
 b) **CONNECT TO NP, PS, IR, IL** for valve without fieldbus communication  
 c) **CONNECT TO BC, BP, EH, EW, EI, EP** for valve with fieldbus communication
- Communication established, valve is **ON-LINE** and it is possible change parameters



**NOTE: Bluetooth adapter available!**  
 For more info please refer to **STARTUP BLUETOOTH** guide

**REMARK:** once removed the USB cable E-C-SB-USB/M12, screw the plastic protection cap **P5** applying the correct tightening torque, in order to preserve valve's IP protection characteristics

**4.2 FIELDBUS - Network Management - only for BC, BP, EH, EW, EI, EP**

Node, Station Alias, IP Address, Baudrate, etc... can be set through:  
 1) **Machine central unit (master)** - please refer to E-MAN-S-\*\* fieldbus protocol programming manual  
 2) **E-SW software**  
 • switch to **Level 2 - Advanced** and browse to **Network Management - Configuration** to change below default settings:


<b>BC CANopen</b> Configuration file: <b>EDS</b> Configuration CANopen Node: 1 Speed: 50 Kbit/sec Filter Active	<b>BP PROFIBUS DP</b> Configuration file: <b>GSD</b> Defaults: Telegram 3 for <b>SN</b> Telegram 5 for <b>SP, SF, SL</b>	Configuration Profibus Node: 125 Telegram Selection: Telegram 5
<b>EH EtherCAT</b> Configuration file: <b>XML</b> Station Alias is assigned automatically by fieldbus master	<b>EW POWERLINK</b> Configuration file: <b>XDD</b>	Configuration Node ID: 125
<b>EI EtherNet/IP</b> Configuration file: <b>EDS</b> IP Address, Subnet Mask and Default Gateway are assigned by fieldbus master, IPConfig or BOOTP/DHCP utility	<b>EP PROFINET</b> Configuration file: <b>GSDML</b> IP Address, Subnet Mask, Default Gateway and Station Name are assigned automatically by fieldbus master (e.g. Discovery and Configuration Protocol)	Configuration IP Address: 0.0.0.0 Subnet Mask: 0.0.0.0 Default Gateway: 0.0.0.0

- press **Memory Store** button and in **Fieldbus Parameters** press **Store User** button to save new setting into the driver (see 4.6)
- network configuration settings will be applied at next driver power-on or pressing the **Restart** button

**NOTE:** configuration files are available in USB memory stick of the software or in MyAtos area - [www.atos.com](http://www.atos.com)

**4.3 REFERENCES - only for BC, BP, EH, EW, EI, EP**

The source of reference signals for valves with fieldbus:  
 • is preset as **Analog** by factory default  
 • can be managed through machine control unit by setting the source from **Analog to Fieldbus**




**4.4 P/Q SETUP - only for SP, SF, SL**

The scaling procedure of the remote transducers feedbacks and pressure/force PID tuning are mandatory!  
 Please refer to E-MAN-RI-LES-S operating manual.

**WARNING:** the system may be damaged and/or perform uncontrolled movements, due to vibrations and/or undesired transitions between controls P and Q or not executing at all the pressure/force limitation, if the operations listed in this paragraph are not performed.

**4.5 SMART TUNING - E-SW level 2 functionality**

Smart tuning allows to adjust the valve dynamic response in order to match different performance requirements.



**NOTE:** smart tuning function not available for LIQZP-TEs cartridges

**4.6 STORE**

- Parameters modifications will be stored into driver permanent memory:
- press **Memory Store** button to access **Driver - Memory Store** window
  - press **Store User** buttons to store **Valve Parameters** or **Fieldbus Parameters**

**WARNING:** During valve or fieldbus parameters storing operations, the driver automatically shuts down the solenoid power supply for a short time. Do not perform any storing commands while the system is working.

**4.7 BACK UP**

- Parameter modifications will be saved into PC memory:
- press **Save** button to access **Computer SW Archive - Setting Files** page, **Setting File Name** pop-up appears
  - input a valid name into **Description** field and press **Ok** button

**TROUBLESHOOTING**

- Valve vibration or noise**  
 • presence of air in the solenoid; perform air bleeding procedure – see STEP 3
- The valve does not follow the reference signal**  
 • valve is powered off, verify presence of 24 Vdc power supply  
 • valve is disabled, verify presence of 24 Vdc on enable pin - only for /Q and /Z options  
 • spool sticking, contact Atos service center  
 • missing piloting pressure, verify that hydraulic power level is compliant with valve's characteristics
- Software parameters modifications are lost when valve is switched off**  
 • parameter store operation was not performed, check store procedure – see STEP 4, section 4.6
- Software parameters modifications have no effect on the valve**  
 • valve is OFF LINE, check connection procedure – see STEP 4, section 4.1
- After the modifications of software parameters the valve does not work properly**  
 • restore valve factory parameters using 'Restore Factory' button, located in 'Driver - Memory Store' window:  
 - during restore, the current to the solenoid(s) will be temporarily switched to off!  
 - factory parameters will be applied at next driver restart or after power off-on sequence!