

**DIRECT OPERATED PROPORTIONAL DIRECTIONAL AND FLOW VALVES**

**Valve model:**  
 DHZO-TES DKZOR-TES QVHZO-TES  
 DLHZO-TES DLKZOR-TES QVKZOR-TES

**Driver models:**  
 E-RI-RES-N for directional and flow valves without alternated P/Q control **SN**  
 E-RI-RES-S for directional valves with alternated P/Q control **SP, SF, SL**

**IDENTIFICATION**

Valve identification plates and label

Valve name plate : N

1 : valve code  
 2 : valve matrix code  
 3 : hydraulic symbol

Driver label : L

4 : driver code  
 5 : driver serial number  
 6 : factory firmware version

**INSTALLATION TOOLS ACCORDING TO VALVE MODEL- not included**

| Fastening bolts       | Wrenches                             | Main connectors                                    | Fieldbus connectors                                  | Transducers cables                        |
|-----------------------|--------------------------------------|--|--|---|
| socket head screws    | for fastening bolts and air bleeding | SN, SN,SP,SF,SL<br>7 pin metallic, 12 pin metallic | BC,BP, EH,EW,EI,EP<br>5 pin metallic, 4 pin metallic | SP,SL, SF<br>5 pin plastic, 5 pin plastic |
| see STEP 1 and STEP 3 |                                      | see STEP 2.1                                       | see STEP 2.2   | see STEP 2.3                              |

**PROGRAMMING TOOLS - not included**

| Software                    | USB connection KIT                                | OR | Bluetooth connection KIT                         |
|-----------------------------|---|----|--|
| E-SW-* programming software | Cable, Isolator<br>E-C-SB-USB/M12, E-A-SB-USB/OPT |    | Cable, Adapter<br>E-C-SB-M12/BTH, E-A-SB-USB/BTH |

**PROGRAMMING SOFTWARE**

The software is available in different versions according to the driver's options:

| Software      | supports | NP (USB)                                      | IL (IO-Link)                       | PS (Serial)                         | IR (Infrared) |
|---------------|----------|---|------------------------------------|-------------------------------------|---------------|
| E-SW-BASIC    | supports | NP (USB)                                      | IL (IO-Link)                       | PS (Serial)                         | IR (Infrared) |
| E-SW-FIELDBUS | supports | BC (CANopen), EW (POWERLINK)                  | BP (PROFIBUS DP), EI (EtherNet/IP) | EH (EtherCAT), EP (PROFINET RT/IRT) |               |
| E-SW-/PQ      | supports | valves with SP, SF, SL alternated P/Q control |                                    |                                     |               |

E-SW-FIELDBUS supports also valves without fieldbus communication; E-SW-/PQ supports also valves without P/Q control

**REMARK** Atos software is designed for Windows based operative systems - Windows XP SP3 or later

**DOWNLOAD AREA**

Perform the registration at [www.atos.com/en-it/login](http://www.atos.com/en-it/login) by filling the form. In MyAtos area, perform login with personal username and password and then press the **Download area electronics** button

Free version of E-SW-BASIC can be downloaded and used by the "FREE Activation Code"

The software remains active for 10 days from the installation date and then it stops until the user inputs the Activation Code

**RELATED DOCUMENTATION - www.atos.com - section Catalog on-line**

|   |  |
|---|--|
| FS900 Operating and maintenance information - tech. table | STARTUP E-SW-BASIC Software startup guide                      |
| FS500 Digital proportional valves with P/Q - tech. table  | STARTUP E-SW-FIELDBUS Software startup guide                   |
| FS165 DHZO, DKZOR positive spool overlap - tech. table    | STARTUP BLUETOOTH Bluetooth adapter startup guide              |
| FS168 DHZO, DKZOR zero spool overlap - tech. table        | E-MAN-RI-LES TES/LES - driver operating manual                 |
| FS180 DLHZO, DLKZOR servoproportional - tech. table       | E-MAN-RI-LES-S TES/LES - driver with S option operating manual |
| FS412 QVHZO, QVKZOR flow controls - tech. table           | E-MAN-S-BC CANopen protocol programming manual                 |
| P005 Mounting surface - tech. table                       | E-MAN-S-BP PROFIBUS DP protocol programming manual             |
| GS500 Programming tools - tech. table                     | E-MAN-S-EH EtherCAT protocol programming manual                |
| GS510 Fieldbus - tech. table                              | E-MAN-S-EW POWERLINK protocol programming manual               |
| K800 Electric and electronic connectors - tech. table     | E-MAN-S-EI EtherNet/IP protocol programming manual             |
|   | E-MAN-S-EP PROFINET protocol programming manual                |

**ATTENTION!**

The purpose of this quickstart guide is show a logical sequence of basic operations. This guide does not cover all details or variants of Atos valves. All operations described in this document should be performed only by qualified personnel. Operations and images could be subject to change without notice. For further information please refer to related documentation.

**PRODUCTS OVERVIEW**

| INSTALLATION |            |            | PROGRAMMING |
|--------------|------------|------------|-------------|
| STEP 1       | STEP 2     | STEP 3     | STEP 4      |
| MECHANICAL   | ELECTRICAL | HYDRAULICS | SOFTWARE    |

**STEP 1 MECHANICAL**

In case of first commissioning, before the valve installation the whole system must be correctly flushed to grant the required cleanliness level  
 During the flushing operation use on-off or by-pass valves in place of the proportional valve

- remove protection pad **P1** located on the valve bottom face only immediately before installation (do not remove connectors caps)
- check the presence and correct positioning of the seals on valve ports
- verify that valve mounting surface is clean and free from damages or burrs
- verify the correct valve orientation according to the pattern of the relevant mounting interface
- lock the fastening bolts respecting below sequence and tightening torque according to valve model

| DHZO-TES / DLHZO-TES  | DKZOR-TES / DLKZOR-TES  |
|---|---|
| <p>Mounting surface layout</p> <p>4401-03-02-0-05 n°1 OR 2025 for option /Y<br/>                     4401-03-03-0-05 (for /Y without X port)<br/>                     Valve size ISO 4401: 06</p> <p>Fastening bolts socket head screws n°4 M5x50 class:12.9 wrench 4 mm</p> <p>Tightening torque: 8 Nm</p> | <p>Mounting surface layout</p> <p>4401-05-04-0-05 n°1 OR 108 for option /Y<br/>                     4401-05-05-0-05 (for /Y without X port)<br/>                     Valve size ISO 4401: 10</p> <p>Fastening bolts socket head screws n°4 M6x40 class:12.9 wrench 5 mm</p> <p>Tightening torque: 15 Nm</p> |

| QVHZO-TES   | QVKZOR-TES   |
|---|--|
| <p>Mounting surface layout</p> <p>4401-03-02-0-05 Valve size ISO 4401: 06</p> <p>Fastening bolts socket head screws n°4 M5x50 class:12.9 wrench 4 mm</p> <p>Tightening torque: 8 Nm</p> | <p>Mounting surface layout</p> <p>4401-05-04-0-05 Valve size ISO 4401: 10</p> <p>Fastening bolts socket head screws n°4 M6x40 class:12.9 wrench 5 mm</p> <p>Tightening torque: 15 Nm</p> |

**STEP 2 ELECTRICAL**

This section considers the different valves options, illustrating the multiple variants of the available electrical connections. The electrical connections have to be wired according to the selected valve code

**WARNING:** for electrical connections of safety proportional valves please refer to technical tables:  
**FY100** safety proportionals /U with double power supply - **FY200** safety proportionals /K with on-off signals

**2.1 MAIN CONNECTOR**

1 Remove main connector cap **P2**

2 Select main connector according to valve code and proceed with wirings operations

Recommended LiYCY shielded cables:  
 7 x 0,75 mm² max 20 m  
 7 x 1 mm² max 40 m

Recommended LiYCY shielded cable:  
 12 x 0,75 mm² max 20 m

**WARNING:** remove power supply before any electrical or wiring operations

3 Connect the valve to the system

ZM-7P - 7 pin MAIN CONNECTOR

ZM-12P - 12 pin MAIN CONNECTOR

**NOTE:** the use of above metallic connectors is strongly recommended in order to fulfill EMC requirements

**WARNING:** a safety fuse is required in series to driver power supply - 2,5 A time lag fuse

| SN standard                     | SN /Z option                    |
|---------------------------------|---------------------------------|
| A V+ (power supply 24Voc)       | 1 V+ (power supply 24Voc)       |
| B V0 (power supply 0Voc)        | 2 V0 (power supply 0Voc)        |
| C AGND (input 24Voc)            | 3 ENABLE (input 24Voc)          |
| D Q_INPUT+ (±10Voc / 4 + 20mA)  | 4 Q_INPUT+ (±10Voc / 4 + 20mA)  |
| E INPUT- (±10Voc / 4 + 20mA)    | 5 INPUT- (±10Voc / 4 + 20mA)    |
| F Q_MONITOR (±10Voc / 4 + 20mA) | 6 Q_MONITOR (±10Voc / 4 + 20mA) |
| G EARTH                         | 7 NC                            |
|                                 | 8 NC                            |
|                                 | 9 VL+ (power supply 24Voc)      |
|                                 | 10 VL0 (power supply 0Voc)      |
|                                 | 11 FAULT (output 24Voc)         |
|                                 | PE EARTH                        |

| SN /Q option                    | SN /F option                    |
|---------------------------------|---------------------------------|
| A V+ (power supply 24Voc)       | A V+ (power supply 24Voc)       |
| B V0 (power supply 0Voc)        | B V0 (power supply 0Voc)        |
| C AGND (input 24Voc)            | C AGND (input 24Voc)            |
| D Q_INPUT+ (±10Voc / 4 + 20mA)  | D Q_INPUT+ (±10Voc / 4 + 20mA)  |
| E INPUT- (±10Voc / 4 + 20mA)    | E INPUT- (±10Voc / 4 + 20mA)    |
| F Q_MONITOR (±10Voc / 4 + 20mA) | F Q_MONITOR (±10Voc / 4 + 20mA) |
| G EARTH                         | G EARTH                         |

| SP, SF, SL standard                   |
|---------------------------------------|
| 1 V+ (power supply 24Voc)             |
| 2 V0 (power supply 0Voc)              |
| 3 ENABLE (input 24Voc)                |
| 4 Q_INPUT+ (±10Voc / 4 + 20mA)        |
| 5 INPUT- (±10Voc / 4 + 20mA)          |
| 6 Q_MONITOR (±10Voc / 4 + 20mA)       |
| 7 F_INPUT+ (±10Voc / 4 + 20mA)        |
| 8 F_MONITOR (±10Voc / 4 + 20mA)       |
| 9 VL+ (power supply 24Voc - fieldbus) |
| 10 VL0 (power supply 0Voc - fieldbus) |
| 11 FAULT (output 24Voc)               |
| PE EARTH                              |

**2.2 FIELDBUS CONNECTORS - only for BC, BP, EH, EW, EI, EP**

1 Remove fieldbus connectors caps **P3**

2 Select fieldbus connectors according to valve code and proceed with wirings operations

M12 Coding A Cable diameter 6 ÷ 8 mm  
 M12 Coding B Cable diameter 6 ÷ 8 mm  
 M12 Coding D Cable diameter 4 ÷ 8 mm

| BC                              | BP   | EH - EW - EI - EP |
|---------------------------------|--|-------------------|
| 1 CAN_SHLD Shield               | 1 +5V Termination supply signal            | 1 TX+ Transmitter |
| 2 not used                      | 2 LINE-A Bus line (high)                   | 2 RX- Receiver    |
| 3 CAN_GND Signal zero data line | 3 DGND Data line - termination signal zero | 3 TX- Transmitter |
| 4 CAN_H Bus line (high)         | 4 LINE-B Bus line (low)                    | 4 RX- Receiver    |
| 5 CAN_L Bus line (low)          | 5 SHIELD                                   | housing SHIELD    |

3 Connect the valve to the fieldbus network. For information about fieldbus terminators see **GS500**. The use of above metallic connectors is strongly recommended in order to fulfill EMC requirements.

BC BP EH, EW, EI, EP

ZM-5PF - 5 pin  
 ZM-5PM - 5 pin

ZM-5PF/BP - 5 pin  
 ZM-5PM/BP - 5 pin

ZM-4PME - 4 pin  
 ZM-4PME/E - 4 pin

**2.3 REMOTE TRANSDUCERS CONNECTOR - only for SP, SF, SL**

1 Remove transducer connector cap **P4**

2 Select transducer(s) connection and proceed with wirings operations

SP, SL - Single Transducer

|                                |
|--------------------------------|
| 1 VF+ 24V (power supply 24Voc) |
| 2 TR1 (0 ÷ 10Voc / 4 + 20mA)   |
| 3 AGND                         |
| 4 NC                           |
| 5 NC                           |

SF - Double Transducers

|                                |
|--------------------------------|
| 1 VF+ 24V (power supply 24Voc) |
| 2 TR1 (0 ÷ 10Voc / 4 + 20mA)   |
| 3 AGND                         |
| 4 TR2 (0 ÷ 10Voc / 4 + 20mA)   |
| 5 NC                           |

Recommended cable:  
 (D1) 3 x 0,25 mm²  
 (D2) 5 x 0,25 mm²

SP, SL


ZH-5PM/1.5 - 1.5 m length  
 ZH-5PM/5 - 5 m length  
 5 pin plastic - single cable

SF


ZH-5PM-2/2 - 2 m length  
 4 pin - plastic - double cable

**ELECTRICAL WIRING EXAMPLES**


**MAIN CONNECTOR - VOLTAGE**




**MAIN CONNECTOR - CURRENT**




**REFERENCE INPUT - COMMON MODE**




**REFERENCE INPUT - COMMON MODE**




**MONITOR OUTPUT**




**MONITOR OUTPUT**




**REMOTE TRANSDUCER - only for SP, SL**



**REMOTE TRANSDUCERS - only for SF**



**STEP 3 HYDRAULICS**



**Air bleeding - only DHZO, DLHZO, DKZOR and DLKZOR:**

- release 2 or 3 turns the air bleed screw **V**
- cycle the valve at low pressure until the oil leaking from the **V** port is exempted from air bubbles
- lock the air bleed screw **V**

**NOTE:** to facilitate bleeding operations, apply a light backpressure (1 or 2 bar) by adding a check valve on T line for standard valves or on Y line for valves with /Y option

Consult tech table **FS900** for general guidelines about component's commissioning

**HINT ! - Wizard objects dictionary - only for BC, BP, EH, EW, EI, EP**

Press **CTRL + H** on the PC keyboard to open the context help form

Move arrow on parameter (e.g. **Unit**) to display the objects dictionary information to access the parameter via fieldbus

If present **List**, press **→** to display values accepted by the parameter

**NOTE:** alternatively right click on any parameter

**STEP 4 SOFTWARE**

**REMARK** proportional valves with integral electronics are factory preset with default parameters, only few programming operations are mandatory for:


- BC, BP, EH, EW, EI, EP** setup the network parameters and the source of reference signals
- SP, SF, SL** setup the feedback's scale for remote transducers and the pressure/force PID parameters

Valve programming can be performed through E-SW software or via fieldbus (not for NP)

| PROGRAMMING |          |            |           |              |       | PC      |
|-------------|----------|------------|-----------|--------------|-------|---------|
| 4.1         | 4.2      | 4.3        | 4.4       | 4.5          | 4.6   | 4.7     |
| CONNECTION  | FIELDBUS | REFERENCES | P/Q SETUP | SMART TUNING | STORE | BACK UP |

**4.1 CONNECTION**

- In order to access valve parameterization:
  - Install E-SW software on PC
  - Insert main connector to the valve and power on with 24Vdc
- Remove USB plastic protection cap **P5** and connect valve to the PC as shown below



- Launch the software using E-SW icon:
  - software does NOT detect valid connection** communication is not established, please follow wizard procedure
  - software detects valid connection** communication automatically established - valve is **ON-LINE** see 5

- Press buttons according the below sequence:
  - a) ON-LINE - Recommended** Wizard procedure for standard connection
  - b) CONNECT TO NP, PS, IR, IL** for valve without fieldbus communication
  - c) CONNECT TO BC, BP, EH, EW, EI, EP** for valve with fieldbus communication
- Communication established, valve is **ON-LINE** and it is possible change parameters

**NOTE: Bluetooth adapter available!** For more info please refer to STARTUP BLUETOOTH guide

**REMARK:** once removed the USB cable E-C-SB-USB/M12, screw the plastic protection cap **P5** applying the correct tightening torque, in order to preserve valve's IP protection characteristics

Tightening torque **0,6 Nm**

**4.2 FIELDBUS - Network Management - only for BC, BP, EH, EW, EI, EP**

Node, Station Alias, IP Address, Baudrate, etc... can be set through:

- Machine central unit (master)** - please refer to E-MAN-S-\*\* fieldbus protocol programming manual
- E-SW software**
  - switch to **Level 2 - Advanced** and browse to **Network Management - Configuration** to change below default settings:

|  |   |
|--|---|
| <b>BC CANopen</b><br>Configuration file: <b>EDS</b><br>Configuration: CANopen Node 1, Speed 50 Kbit/sec, Filter Active   | <b>BP PROFIBUS DP</b><br>Configuration file: <b>GSD</b><br>Defaults: Telegram 3 for SN, Telegram 5 for SP, SF, SL   |
| <b>EH EtherCAT</b><br>Configuration file: <b>XML</b><br>Station Alias is assigned automatically by fieldbus master   | <b>EW POWERLINK</b><br>Configuration file: <b>XDD</b>   |
| <b>EI EtherNet/IP</b><br>Configuration file: <b>EDS</b><br>IP Address, Subnet Mask and Default Gateway are assigned by fieldbus master, IPconfig or BOOTP/DHCP utility | <b>EP PROFINET</b><br>Configuration file: <b>GSDML</b><br>IP Address, Subnet Mask, Default Gateway and Station Name are assigned automatically by fieldbus master (e.g. Discovery and Configuration Protocol) |

- press **Memory Store** button and in **Fieldbus Parameters** press **Store User** button to save new setting into the driver (see 4.6)
  - network configuration settings will be applied at next driver power-on or pressing the **Restart** button
- NOTE:** configuration files are available in E-SW DVD or in MyAtos area - [www.atos.com](http://www.atos.com)

**4.3 REFERENCES - only for BC, BP, EH, EW, EI, EP**

The source of reference signals for valves with fieldbus:

- is preset as **Analog** by factory default
- can be managed through machine control unit by setting the source from **Analog to Fieldbus**

- For **SN, SP, SF, SL** with fieldbus:
  - in **Flow - Reference** select **Fieldbus**
- Only for **SP, SF, SL** with fieldbus:
  - in **Pressure/Force - Reference** select **Fieldbus**

**4.4 P/Q SETUP - only for SP, SF, SL**

The scaling procedure of the remote transducers feedbacks and pressure/force PID tuning are mandatory! Please refer to E-MAN-RI-LES-S operating manual.

**WARNING:** the system may be damaged and/or perform uncontrolled movements, due to vibrations and/or undesired transitions between controls P and Q or not executing at all the pressure/force limitation, if the operations listed in this paragraph are not performed.

**4.5 SMART TUNING - E-SW level 2 functionality**

Smart tuning allows to adjust the valve dynamic response in order to match different performance requirements.

The valve is provided with 3 factory setting for the spool control

- PID1 Dynamic:** Fast response time and high sensitivity for best dynamic performances - default
- PID2 Balanced:** Average response time and sensitivity suitable for major applications
- PID3 Smooth:** Attenuated response time and sensitivity to improve control stability in critical applications or in environments with electrical disturbances

**4.6 STORE**

Parameters modifications will be stored into driver permanent memory:

- press **Memory Store** button to access **Driver - Memory Store** window
- press **Store User** buttons to store **Valve Parameters** or **Fieldbus Parameters**

**WARNING:** During valve or fieldbus parameters storing operations, the driver automatically shuts down the solenoid power supply for a short time. Do not perform any storing commands while the system is working.

**4.7 BACK UP**

Parameter modifications will be saved into PC memory:

- press **Save** button to access **Computer SW Archive - Setting Files** page, **Setting File Name** pop-up appears
- input a valid name into **Description** field and press **Ok** button

**TROUBLESHOOTING**

**Valve vibration or noise**

- presence of air in the solenoid; perform air bleeding procedure - see STEP 3

**The valve does not follow the reference signal**

- valve is powered off, verify presence of 24 Vdc power supply
- valve is disabled, verify presence of 24 Vdc on enable pin - only for /Q and /Z options
- flow/pressure values exceeding the valve's performance limits, verify that hydraulic operating conditions are in compliance with the valve's characteristics
- spool sticking, contact Atos service center

**Software parameters modifications are lost when valve is switched off**

- parameter store operation was not performed, check store procedure - see STEP 4, section 4.6

**Software parameters modifications have no effect on the valve**

- valve is OFF LINE, check connection procedure - see STEP 4, section 4.1

**After the modifications of software parameters the valve does not work properly**

- restore valve factory parameters using 'Restore Factory' button, located in 'Driver - Memory Store' window:
  - during restore, the current to the solenoid(s) will be temporarily switched to off!
  - factory parameters will be applied at next driver restart or after power off-on sequence!