


## DIRECT OPERATED PROPORTIONAL DIRECTIONAL AND FLOW VALVES

**Valve model:**  
DHZO-TES DKZOR-TES QVHZO-TES  
DLHZO-TES DLKZOR-TES QVKZOR-TES


**Driver models:**  
E-RI-TES-N for directional and flow valves without alternated p/Q control **SN**  
E-RI-TES-S for directional valves with alternated p/Q control **SP, SF, SL**

## IDENTIFICATION

Valve identification plates and label




Valve name plate : **N**











1 : valve code  
2 : valve matrix code  
3 : hydraulic symbol

Driver label : **L**








4 : driver code  
5 : driver serial number  
6 : factory firmware version

## INSTALLATION TOOLS ACCORDING TO VALVE MODEL- not included

Fastening bolts	Wrenches	Main connectors		Fieldbus connectors		Transducers cables	
		<b>SN</b>	<b>SN,SP,SF,SL</b>	<b>BC,BP</b>	<b>EH,EW,EI,EP</b>	<b>SP,SL</b>	<b>SF</b>
							
see STEP 1 and STEP 3		see STEP 2.1		see STEP 2.2		see STEP 2.3	

## PROGRAMMING TOOLS - not included

PC software	mobile App	Bluetooth	OR	USB connection KIT	
					
<b>E-SW-SETUP</b>	<b>Atos CONNECT</b>	<b>E-A-BTH</b>		<b>E-C-SB-USB/M12</b>	<b>E-A-SB-USB/OPT</b>


**NOTE:** Atos CONNECT supports Atos digital valve drivers equipped with E-A-BTH or with built-in Bluetooth, see STEP 5

## PC SOFTWARE

<b>E-SW-SETUP</b>	supports	<b>NP</b> (USB) <b>BC</b> (CANopen) <b>EW</b> (POWERLINK) supports valves with <b>SP, SF, SL</b> alternated p/Q control	<b>IL</b> (IO-Link) <b>BP</b> (PROFIBUS DP) <b>EI</b> (EtherNet/IP)	<b>PS</b> (Serial) <b>EH</b> (EtherCAT) <b>EP</b> (PROFINET RT/IRT)	<b>IR</b> (Infrared)
-------------------	----------	--	---	---	----------------------

**REMARK** Atos PC software is designed for Windows based operative systems - Windows 10 or later

## PC SOFTWARE DOWNLOAD



Download PC software at [www.atos.com](http://www.atos.com) accessing to "MyAtos -> Download area electronics"

Free registration by filling the form at [www.atos.com/en-it/login](http://www.atos.com/en-it/login)

E-SW-SETUP is free and available in Download area

## RELATED DOCUMENTATION - www.atos.com

<b>FS900</b> Operating and maintenance information - tech. table	<b>STARTUP BLUETOOTH</b> Bluetooth adapter startup guide
<b>FS500</b> Digital proportional valves with p/Q - tech. table	<b>E-MAN-RI-LES</b> TES/LES - driver operating manual
<b>FS165</b> DHZO, DKZOR positive spool overlap - tech. table	<b>E-MAN-RI-LES-S</b> TES/LES - driver with S option operating manual
<b>FS168</b> DHZO, DKZOR zero spool overlap - tech. table	<b>E-MAN-S-BC</b> CANopen protocol programming manual
<b>FS180</b> DLHZO, DLKZOR servoproportional - tech. table	<b>E-MAN-S-BP</b> PROFIBUS DP protocol programming manual
<b>FS412</b> QVHZO, QVKZOR flow controls - tech. table	<b>E-MAN-S-EH</b> EtherCAT protocol programming manual
<b>P005</b> Mounting surface - tech. table	<b>E-MAN-S-EW</b> POWERLINK protocol programming manual
<b>GS500</b> Programming tools - tech. table	<b>E-MAN-S-EI</b> EtherNet/IP protocol programming manual
<b>GS510</b> Fieldbus - tech. table	<b>E-MAN-S-EP</b> PROFINET protocol programming manual
<b>K800</b> Electric and electronic connectors - tech. table	

## ATTENTION !

The purpose of this quickstart guide is show a logical sequence of basic operations. This guide does not cover all details or variants of Atos valves. All operations described in this document should be performed only by qualified personnel. Operations and images could be subject to change without notice. For further information please refer to related documentation.

## CONTACT US


Atos spa - Italy - 21018 Sesto Calende

[www.atos.com](http://www.atos.com)


[support@atos.com](mailto:support@atos.com)

## PRODUCTS OVERVIEW


STEP 1




STEP 2.1




STEP 2.2



STEP 2.3




STEP 4



INSTALLATION			PROGRAMMING	
STEP 1	STEP 2	STEP 3	STEP 4	STEP 5
MECHANICAL	ELECTRICAL	HYDRAULICS	PC SOFTWARE	MOBILE APP

## STEP 1 MECHANICAL




In case of first commissioning, before the valve installation the whole system must be correctly flushed to grant the required cleanliness level  
During the flushing operation use on-off or by-pass valves in place of the proportional valve

- remove protection pad **P1** located on the valve bottom face only immediately before installation (do not remove connectors caps)
- check the presence and correct positioning of the seals on valve ports
- verify that valve mounting surface is clean and free from damages or burrs
- verify the correct valve orientation according to the pattern of the relevant mounting interface
- lock the fastening bolts respecting below sequence and tightening torque according to valve model


**DHZO-TES / DLHZO-TES**

Mounting surface layout



Valve size ISO 4401: **06**


Fastening bolts socket head screws



n°4 M5x50 class:12.9


wrench 4 mm

Tightening torque: **8 Nm**




**DKZOR-TES / DLKZOR-TES**

Mounting surface layout



Valve size ISO 4401: **10**


Fastening bolts socket head screws



n°4 M6x40 class:12.9


wrench 5 mm

Tightening torque: **15 Nm**




**QVHZO-TES**

Mounting surface layout



Valve size ISO 4401: **06**


Fastening bolts socket head screws



n°4 M5x50 class:12.9


wrench 4 mm

Tightening torque: **8 Nm**




**QVKZOR-TES**

Mounting surface layout



Valve size ISO 4401: **10**


Fastening bolts socket head screws



n°4 M6x40 class:12.9

wrench 5 mm

Tightening torque: **15 Nm**




## STEP 2 ELECTRICAL

This section considers the different valves options, illustrating the multiple variants of the available electrical connections. The electrical connections have to be wired according to the selected valve code


**WARNING:** for electrical connections of safety proportional valves please refer to technical tables:  
**FY100** safety proportionals **/U** with double power supply - **FY200** safety proportionals **/K** with on-off signals

## 2.1 MAIN CONNECTOR

1 Remove main connector cap **P2**




2 Select main connector according to valve code and proceed with wirings operations



Recommended LiYY shielded cables:  
7 x 0,75 mm<sup>2</sup> max 20 m  
7 x 1 mm<sup>2</sup> max 40 m

Recommended LiYY shielded cable:  
12 x 0,75 mm<sup>2</sup> max 20 m

3 Connect the valve to the system



**ZM-7P - 7 pin MAIN CONNECTOR**

**ZM-12P - 12 pin MAIN CONNECTOR**

**NOTE:** the use of above metallic connectors is strongly recommended in order to fulfill EMC requirements

**WARNING:** a safety fuse is required in series to driver power supply - 2,5 A time lag fuse


SN standard		SN /Z option	
A	V+ (power supply 24Voc)	1	V+ (power supply 24Voc)
B	V0 (power supply 0Voc)	2	V0 (power supply 0Voc)
C	AGND	3	ENABLE (input 24Voc)
D	Q_INPUT+ (±10Voc / 4 ÷ 20mA)	4	Q_INPUT+ (±10Voc / 4 ÷ 20mA)
E	INPUT- (±10Voc / 4 ÷ 20mA)	5	INPUT- (±10Voc / 4 ÷ 20mA)
F	Q_MONITOR (±10Voc / 4 ÷ 20mA)	6	Q_MONITOR (±10Voc / 4 ÷ 20mA)
G	EARTH	7	NC
		8	NC
		9	VL+ (power supply 24Voc)
		10	VL0 (power supply 0Voc)
		11	FAULT (output 24Voc)
		PE	EARTH

SN /Q option		SN /F option	
A	V+ (power supply 24Voc)	A	V+ (power supply 24Voc)
B	V0 (power supply 0Voc)	B	V0 (power supply 0Voc)
C	ENABLE (input 24Voc)	C	AGND
D	Q_INPUT+ (±10Voc / 4 ÷ 20mA)	D	Q_INPUT+ (±10Voc / 4 ÷ 20mA)
E	INPUT- (±10Voc / 4 ÷ 20mA)	E	INPUT- (±10Voc / 4 ÷ 20mA)
F	Q_MONITOR (±10Voc / 4 ÷ 20mA)	F	FAULT (output 24Voc)
G	EARTH	G	EARTH


SP, SF, SL standard	
1	V+ (power supply 24Voc)
2	V0 (power supply 0Voc)
3	ENABLE (input 24Voc)
4	Q_INPUT+ (±10Voc / 4 ÷ 20mA)
5	INPUT- (±10Voc / 4 ÷ 20mA)
6	Q_MONITOR (±10Voc / 4 ÷ 20mA)
7	F INPUT+ (±10Voc / 4 ÷ 20mA)
8	F MONITOR (±10Voc / 4 ÷ 20mA)
9	D_IN0 (multiple PID selection - NP)
10	VL+ (power supply 24Voc - fieldbus)
11	D_IN1 (multiple PID selection - NP)
12	VL0 (power supply 0Voc - fieldbus)
13	FAULT (output 24Voc)
14	PE EARTH

## 2.2 FIELDBUS CONNECTORS - only for BC, BP, EH, EW, EI, EP

1 Remove fieldbus connectors caps **P3**



2 Select fieldbus connectors according to valve code and proceed with wirings operations



M12 Coding A Cable diameter 6 ÷ 8 mm


M12 Coding B Cable diameter 6 ÷ 8 mm

M12 Coding D Cable diameter 4 ÷ 8 mm


BC		BP		EH - EW - EI - EP	
1	CAN_SHLD Shield	1	+5V Termination supply signal	1	TX+ Transmitter
2	not used	2	LINE-A Bus line (high)	2	RX- Receiver
3	CAN_GND Signal zero data line	3	DGND Data line - termination signal zero	3	TX- Transmitter
4	CAN_H Bus line (high)	4	LINE-B Bus line (low)	4	RX+ Receiver
5	CAN_L Bus line (low)	5	SHIELD		housing SHIELD

3 Connect the valve to the fieldbus network. For information about fieldbus terminators see **GS500**. The use of above metallic connectors is strongly recommended in order to fulfill EMC requirements.


**BC**




**BP**




**EH, EW, EI, EP**




**ZM-5PF - 5 pin**




**ZM-5PM - 5 pin**




**ZM-5PF/BP - 5 pin**




**ZM-5PM/BP - 5 pin**




**ZM-4PME - 4 pin**




**ZM-4PME/E - 4 pin**






## 2.3 REMOTE TRANSDUCERS CONNECTOR - only for SP, SF, SL

1 Remove transducer connector cap **P4**



2 Select transducer(s) connection and proceed with wirings operations




Recommended cable:  
① 3 x 0,25 mm<sup>2</sup>  
② 5 x 0,25 mm<sup>2</sup>


SP, SL - Single Transducer	
1	VF+ 24V (power supply 24Voc)
2	TR1 (0 ÷ 10Voc / 4 ÷ 20mA)
3	AGND
4	NC
5	NC

SF - Double Transducers	
1	VF+ 24V (power supply 24Voc)
2	TR1 (0 ÷ 10Voc / 4 ÷ 20mA)
3	AGND
4	TR2 (0 ÷ 10Voc / 4 ÷ 20mA)
5	NC

3 Connect the valve to the transducer(s)



**SP, SL**




**ZH-5PM/1.5 - 1.5 m length**

**ZH-5PM/5 - 5 m length**

5 pin plastic - single cable

**SF**




**ZH-5PM-2/2 - 2 m length**

4 pin - plastic - double cable


## ELECTRICAL WIRING EXAMPLES

### MAIN CONNECTOR - VOLTAGE


#### REFERENCE INPUT - DIFFERENTIAL MODE




#### REFERENCE INPUT - COMMON MODE




#### MONITOR OUTPUT



### REMOTE TRANSDUCER - only for SP, SL



## STEP 3 HYDRAULICS



#### Air bleeding - only DHZO, DLHZO, DKZOR and DLKZOR:

- release 2 or 3 turns the air bleed screw **V**
- cycle the valve at low pressure until the oil leaking from the **V** port is exempted from air bubbles
- lock the air bleed screw **V**

**NOTE:** to facilitate bleeding operations, apply a light backpressure (1 or 2 bar) by adding a check valve on T line for standard valves or on Y line for valves with /Y option


Consult tech table **FS900** for general guidelines about component's commissioning

## HINT ! - Wizard objects dictionary - only for BC, BP, EH, EW, EI, EP

Press **CTRL + H** on the PC keyboard to open the context help form

Move arrow on parameter (e.g. **Unit**) to display the objects dictionary information to access the parameter via fieldbus

If present **List**, press **→** to display values accepted by the parameter



**NOTE:** alternatively right click on any parameter




## STEP 4 PC SOFTWARE

**REMARK** proportional valves with on-board electronics are factory preset with default parameters, only few programming operations are mandatory for:


- BC, BP, EH, EW, EI, EP** setup the network parameters and the source of reference signals
  - SP, SF, SL** setup the feedback's scale for remote transducers and the pressure/force PID parameters
- Valve programming can be performed through E-SW-SETUP software or via fieldbus (not for NP)

### 4.1 CONNECTION

- In order to access valve parameterization:**
  - Install E-SW-SETUP software on PC
  - Insert main connector to the valve and power on with **24Vdc**
- Remove USB plastic protection cap **P5** and connect valve to the PC as shown below via Bluetooth (adapter only) or USB (cable and isolator adapter)





- Launch the PC software using E-SW-SETUP icon:
  - PC software does NOT detect valid connection** communication is not established, please follow wizard procedure
  - PC software detects valid connection** communication automatically established - valve is **ON-LINE** see
- In **ON-LINE** - Wizard press button:
  - a) WIRELESS CONNECTION** Wizard procedure for connection via Bluetooth
  - b) CABLE CONNECTION** Wizard procedure for connection via USB cable



**NOTE:** for more info about E-A-BTH Bluetooth adapter, please refer to STARTUP BLUETOOTH guide

**REMARK:** once removed the E-A-BTH Bluetooth adapter or E-C-SB-USB/M12 USB cable, screw the plastic protection cap **P5** applying the correct tightening torque, in order to preserve valve's IP protection characteristics



### 4.2 FIELDBUS - Network Management - only for BC, BP, EH, EW, EI, EP

Node, Station Alias, IP Address, Baudrate, etc... can be set through:

- Machine central unit (master)** - please refer to E-MAN-S-\*\* fieldbus protocol programming manual
- E-SW-SETUP software**
  - browse to **Network Management - Configuration** to change below default settings:

<b>BC</b> CANopen Configuration file: <b>EDS</b>	<b>BP</b> PROFIBUS DP Configuration file: <b>GSD</b> Defaults: Telegram 3 for <b>SN</b> Telegram 5 for <b>SP, SF, SL</b>
<b>EH</b> EtherCAT Configuration file: <b>XML</b>  Station Alias is assigned automatically by fieldbus master	<b>EW</b> POWERLINK Configuration file: <b>XDD</b>
<b>EI</b> EtherNet/IP Configuration file: <b>EDS</b> IP Address, Subnet Mask and Default Gateway are assigned by fieldbus master, IPconfig or BOOTP/DHCP utility	<b>EP</b> PROFINET Configuration file: <b>GSDML</b> IP Address, Subnet Mask, Default Gateway and Station Name are assigned automatically by fieldbus master (e.g. Discovery and Configuration Protocol)


- press **Memory Store** button and press **Save User Set** button to save new setting into the driver (see 4.6)
- network configuration settings will be applied at next driver power on or pressing the **Restart** button

**NOTE:** configuration files are available in MyAtos area - [www.atos.com](http://www.atos.com)

### 4.3 REFERENCES - only for BC, BP, EH, EW, EI, EP

The source of reference signals for valves with fieldbus:

- is preset as **Analog** by factory default
- can be managed through machine control unit by setting the source from **Analog** to **Fieldbus**



### 4.4 p/Q SETUP - only for SP, SF, SL

The scaling procedure of the remote transducers feedbacks and pressure/force PID tuning are mandatory! Please refer to E-MAN-RI-LES-S operating manual.


**WARNING:** the system may be damaged and/or perform uncontrolled movements, due to vibrations and/or undesired transitions between controls **p** and **Q** or not executing at all the pressure/force limitation, if the operations listed in this paragraph are not performed.

### 4.5 SMART TUNING - E-SW-SETUP

Smart tuning allows to adjust the valve dynamic response in order to match different performance requirements.

The valve is provided with 3 factory setting for the spool control:

- dynamic** fast response time and high sensitivity for best dynamic performances (default factory setting)
- balanced** average response time and sensitivity suitable for major applications
- smooth** attenuated response time and sensitivity to improve control stability in critical applications or in environments with electrical disturbances



### 4.6 STORE

Parameters modifications will be stored into driver permanent memory:

- press **Memory Store** button to access **Driver - Memory Save** window
- press **Save User Set** button to store **Valve Parameters**

**WARNING:** during valve parameters storing operations, the driver automatically shuts down the solenoid power supply for a short time. Do not perform any storing commands while the system is working.

### 4.7 BACK UP

Parameter modifications will be saved into PC memory:

- press **Save** button to access **Computer SW Archive - Setting Files** page, **Setting File Name** pop-up appears
- input a valid name into **Description** field and press **Ok** button

## STEP 5 MOBILE APP

**ATOS CONNECT** for smartphones and tablets is a free downloadable app which allows quick access to valve main functional parameters and configuration via Bluetooth, thus avoiding physical cable connection and significantly reducing commissioning times.

**ATOS CONNECT** app requirements:

- iOS 14 / Android 9
- Bluetooth Low Energy (BLE), version 4.2 or higher
- Atos digital valves/drivers equipped with E-A-BTH Bluetooth adapter or with built-in Bluetooth



## TROUBLESHOOTING

### Valve vibration or noise

- presence of air in the solenoid; perform air bleeding procedure – see STEP 3

### The valve does not follow the reference signal

- valve is powered off, verify presence of 24 Vdc power supply
- valve is disabled, verify presence of 24 Vdc on enable pin - only for /Q and /Z options
- flow/pressure values exceeding the valve's performance limits, verify that hydraulic operating conditions are in compliance with the valve's characteristics
- spool sticking, contact Atos service center

### PC software parameters modifications are lost when valve is switched off

- parameter store operation was not performed, check store procedure – see STEP 4, section 4.6

### PC software parameters modifications have no effect on the valve

- valve is OFF LINE, check connection procedure – see STEP 4, section 4.1

### After the modifications of PC software parameters the valve does not work properly

- restore valve factory parameters using 'Load Factory Set' button, located in 'Driver - Memory Save' window:
  - during restore, the current to the solenoid(s) will be temporarily switched to off!
  - factory parameters will be applied at next driver restart or after power off-on sequence!