


PILOTED OPERATED PROPORTIONAL DIRECTIONAL VALVES


Valve model:		Valve model:	
DPZO-LES-1	DPZO-LES-4M	DPZO-TES-1	DPZO-TES-4M
DPZO-LES-2	DPZO-LES-6	DPZO-TES-2	DPZO-TES-6
DPZO-LES-4	DPZO-LES-8	DPZO-TES-4	DPZO-TES-8
Driver models:			
E-RI-LES/TES-N for piloted valves without alternated p/Q control SN			
E-RI-LES/TES-S for piloted valves with alternated p/Q control SP, SF, SL			

IDENTIFICATION




Valve identification plates and label

Valve name plate : **M**




1 : valve code
2 : valve matrix code
3 : valve hydraulic symbol

Pilot valve name plate : **N**











4 : pilot valve code
5 : pilot valve matrix code
6 : pilot hydraulic symbol

Driver label : **L**








7 : driver code
8 : driver serial number
9 : factory firmware version

INSTALLATION TOOLS ACCORDING TO VALVE MODEL- not included

Fastening bolts	Wrenches	Main connectors		Fieldbus connectors		Transducers cables	
		SN	SN,SP,SF,SL	BC,BP	EH,EW,EI,EP	SP,SL	SF
							
see STEP 1 and STEP 3		see STEP 2.1		see STEP 2.2		see STEP 2.3	

PROGRAMMING TOOLS - not included


PC software	mobile App	Bluetooth	OR	USB connection KIT	
					
E-SW-SETUP	Atos CONNECT	E-A-BTH		E-C-SB-USB/M12	E-A-SB-USB/OPT

NOTE: Atos CONNECT supports Atos digital valve drivers equipped with E-A-BTH or with built-in Bluetooth, see STEP 5

PC SOFTWARE

E-SW-SETUP	supports	NP (USB)	IL (IO-Link)	PS (Serial)	IR (Infrared)
		BC (CANopen)	BP (PROFIBUS DP)	EH (EtherCAT)	
		EW (POWERLINK)	EI (EtherNet/IP)	EP (PROFINET RT/IRT)	
	supports	valves with SP, SF, SL alternated p/Q control			
REMARK Atos PC software is designed for Windows based operative systems - Windows 10 or later					

PC SOFTWARE DOWNLOAD




WELCOME

enter your email

Password

forgot your password?

Register



Download area electronics

Download PC software at www.atos.com accessing to "MyAtos -> Download area electronics"

Free registration by filling the form at www.atos.com/en-it/login

E-SW-SETUP is free and available in Download area

RELATED DOCUMENTATION - www.atos.com

FS900 Operating and maintenance information - tech. table	STARTUP BLUETOOTH Bluetooth adapter startup guide
FS500 Digital proportional valves with p/Q - tech. table	E-MAN-RI-LES TES/LES - driver operating manual
FS172 DPZO one LVDT positive spool overlap - tech. table	E-MAN-RI-LES-S TES/LES - driver with S option operating manual
FS175 DPZO two LVDT positive spool overlap - tech. table	E-MAN-S-BC CANopen protocol programming manual
FS178 DPZO two LVDT zero spool overlap - tech. table	E-MAN-S-BP PROFIBUS DP protocol programming manual
P005 Mounting surface - tech. table	E-MAN-S-EH EtherCAT protocol programming manual
GS500 Programming tools - tech. table	E-MAN-S-EW POWERLINK protocol programming manual
GS510 Fieldbus - tech. table	E-MAN-S-EI EtherNet/IP protocol programming manual
K800 Electric and electronic connectors - tech. table	E-MAN-S-EP PROFINET protocol programming manual

ATTENTION !

The purpose of this quickstart guide is show a logical sequence of basic operations. This guide does not cover all details or variants of Atos valves. All operations described in this document should be performed only by qualified personnel. Operations and images could be subject to change without notice. For further information please refer to related documentation.

CONTACT US


Atos spa - Italy - 21018 Sesto Calende

www.atos.com


support@atos.com

PRODUCTS OVERVIEW


STEP 1




STEP 2.1




STEP 2.2



STEP 2.3




STEP 3



INSTALLATION			PROGRAMMING	
STEP 1	STEP 2	STEP 3	STEP 4	STEP 5
MECHANICAL	ELECTRICAL	HYDRAULICS	PC SOFTWARE	MOBILE APP

STEP 1 MECHANICAL



P1

In case of first commissioning, before the valve installation the whole system must be correctly flushed to grant the required cleanliness level

During the flushing operation use on-off or by-pass valves in place of the proportional valve


- remove protection pad **P1** located on the valve bottom face only immediately before installation (do not remove connectors caps)
- check the presence and correct positioning of the seals on valve ports
- verify that valve mounting surface is clean and free from damages or burrs
- verify the correct valve orientation according to the pattern of the relevant mounting interface
- lock the fastening bolts respecting below sequence and tightening torque according to valve model

DPZO-LES*-1 DPZO-TES*-1


Mounting surface layout

4401-05-05-0-05


Valve size ISO 4401: 10



Tightening torque: 15 Nm



wrench 5 mm




DPZO-LES*-2 DPZO-TES*-2


Mounting surface layout

4401-07-07-0-05


Valve size ISO 4401: 16



Tightening torque: 15 Nm for M6
70 Nm for M10



wrench 5 mm
wrench 8 mm




DPZO-LES*-4 DPZO-TES*-4


Mounting surface layout

4401-08-08-0-05


Valve size ISO 4401: 25



Tightening torque: 125 Nm



wrench 10 mm




DPZO-LES*-4M DPZO-TES*-4M


Mounting surface layout

4401-08-08-0-05


Valve size ISO 4401: 27



Tightening torque: 125 Nm



wrench 10 mm




DPZO-LES*-6 DPZO-TES*-6


Mounting surface layout

4401-10-09-0-05


Valve size ISO 4401: 32



Tightening torque: 600 Nm



wrench 17 mm




DPZO-LES*-8


Mounting surface layout

4401-10-09-0-05


Valve size ISO 4401: 35



Tightening torque: 600 Nm



wrench 17 mm



STEP 2 ELECTRICAL

This section considers the different valves options, illustrating the multiple variants of the available electrical connections. The electrical connections have to be wired according to the selected valve code




WARNING: for electrical connections of safety proportional valves please refer to technical tables:
FY100 safety proportionals **/U** with double power supply - **FY200** safety proportionals **/K** with on-off signals

2.1 MAIN CONNECTOR



1

Remove main connector cap **P2**



2

Select main connector according to valve code and proceed with wirings operations




Recommended LiYCY shielded cables:
7 x 0,75 mm² max 20 m
7 x 1 mm² max 40 m


Recommended LiYCY shielded cable:
12 x 0,75 mm² max 20 m

3

Connect the valve to the system



NOTE: the use of above metallic connectors is strongly recommended in order to fulfill EMC requirements



WARNING: a safety fuse is required in series to driver power supply - 2,5 A time lag fuse

SN standard		SN /Z option	
A	V+ (power supply 24Vdc)	1	V+ (power supply 24Vdc)
B	V0 (power supply 0Vdc)	2	V0 (power supply 0Vdc)
C	AGND	3	ENABLE (input 24Vdc)
D	Q_INPUT+ (±10Vdc / 4 ÷ 20mA)	4	Q_INPUT+ (±10Vdc / 4 ÷ 20mA)
E	INPUT- (±10Vdc / 4 ÷ 20mA)	5	INPUT- (±10Vdc / 4 ÷ 20mA)
F	Q_MONITOR (±10Vdc / 4 ÷ 20mA)	6	Q_MONITOR (±10Vdc / 4 ÷ 20mA)
G	EARTH	7	NC
		8	NC
		9	VL+ (power supply 24Vdc)
		10	VLO (power supply 0Vdc)
		11	FAULT (output 24Vdc)
		PE	EARTH


SN /Q option		SP, SF, SL standard	
A	V+ (power supply 24Vdc)	1	V+ (power supply 24Vdc)
B	V0 (power supply 0Vdc)	2	V0 (power supply 0Vdc)
C	ENABLE (input 24Vdc)	3	ENABLE (input 24Vdc)
D	Q_INPUT+ (±10Vdc / 4 ÷ 20mA)	4	Q_INPUT+ (±10Vdc / 4 ÷ 20mA)
E	INPUT- (±10Vdc / 4 ÷ 20mA)	5	INPUT- (±10Vdc / 4 ÷ 20mA)
F	Q_MONITOR (±10Vdc / 4 ÷ 20mA)	6	Q_MONITOR (±10Vdc / 4 ÷ 20mA)
G	EARTH	7	VL+ (power supply 24Vdc)
		8	VLO (power supply 0Vdc)
		9	FAULT (output 24Vdc)
		PE	EARTH

SN /F option	
A	V+ (power supply 24Vdc)
B	V0 (power supply 0Vdc)
C	AGND
D	Q_INPUT+ (±10Vdc / 4 ÷ 20mA)
E	INPUT- (±10Vdc / 4 ÷ 20mA)
F	FAULT (output 24Vdc)
G	EARTH

2.2 FIELDBUS CONNECTORS - only for BC, BP, EH, EW, EI, EP


1

Remove fieldbus connectors caps **P3**



2

Select fieldbus connectors according to valve code and proceed with wirings operations



M12 Coding A Cable diameter 6 ÷ 8 mm


M12 Coding B Cable diameter 6 ÷ 8 mm

M12 Coding D Cable diameter 4 ÷ 8 mm


BC		BP		EH - EW - EI - EP	
1	CAN_SHLD Shield	1	+5V Termination supply signal	1	TX+ Transmitter
2	not used	2	LINE-A Bus line (high)	2	RX- Receiver
3	CAN_GND Signal zero data line	3	DGND Data line - termination signal zero	3	TX- Transmitter
4	CAN_H Bus line (high)	4	LINE-B Bus line (low)	4	RX+ Receiver
5	CAN_L Bus line (low)	5	SHIELD		housing SHIELD

3 Connect the valve to the fieldbus network. For information about fieldbus terminators see **GS500**. The use of above metallic connectors is strongly recommended in order to fulfill EMC requirements.


BC



BP




EH, EW, EI, EP



2.3 REMOTE TRANSDUCERS CONNECTOR - only for SP, SF, SL


1

Remove transducer connector cap **P4**



2


Select transducer(s) connection and proceed with wirings operations



Recommended cable:
D1 3 x 0,25 mm²
D2 5 x 0,25 mm²

3

Connect the valve to the transducer(s)






SP, SL
ZH-5PM/1.5 - 1.5 m length
ZH-5PM/5 - 5 m length
5 pin plastic - single cable


SF
ZH-5PM-2/2 - 2 m length
4 pin - plastic - double cable

ELECTRICAL WIRING EXAMPLES

MAIN CONNECTOR - VOLTAGE



REMOTE TRANSDUCER - only for SP, SL



STEP 3 HYDRAULICS

Wrench type

3 mm

Tightening torque

4 Nm

Air bleeding:

- release 2 or 3 turns the air bleed screw **V**
- cycle the valve at low pressure until the oil leaking from the **V** port is exempted from air bubbles
- lock the air bleed screw **V**

NOTE: to facilitate bleeding operations, apply a light backpressure (1 or 2 bar) by adding a check valve on Y line

Consult tech table **FS900** for general guidelines about component's commissioning

WARNING: To avoid overheating and possible damage of the electronic driver, the valves must be never energized without hydraulic supply to the pilot stage. In case of prolonged pauses of the valve operation during the machine cycle, it is always advisable to switch off or disable the driver (option /Q or /Z)

HINT ! - Wizard objects dictionary - only for BC, BP, EH, EW, EI, EP

Press **CTRL + H** on the PC keyboard to open the context help form

Move arrow on parameter (e.g. **Unit**) to display the objects dictionary information to access the parameter via fieldbus

If present **List**, press **→** to display values accepted by the parameter




Flow Reference Analog

Unit Voltage


Unit Voltage

NOTE: alternatively right click on any parameter

MAIN CONNECTOR - CURRENT



REMOTE TRANSDUCERS - only for SF



STEP 4 PC SOFTWARE

REMARK proportional valves with on-board electronics are factory preset with default parameters, only few programming operations are mandatory for:

- BC, BP, EH, EW, EI, EP** setup the network parameters and the source of reference signals
- SP, SF, SL** setup the feedback's scale for remote transducers and the pressure/force PID parameters

Valve programming can be performed through E-SW-SETUP software or via fieldbus (not for NP)

4.1 CONNECTION

1 In order to access valve parameterization:

- Install E-SW-SETUP software on PC
- Insert main connector to the valve and power on with **24Vdc**

2 Remove USB plastic protection cap **P5** and connect valve to the PC as shown below via Bluetooth (adapter only) or USB (cable and isolator adapter)

E-A-BTH Bluetooth adapter

E-C-SB-USB/M12 USB cable length 4m

E-A-SB-USB/OPT USB isolator adapter

E-SW-SETUP installed on PC

WARNING: drivers USB port is not isolated!
The use of USB isolator adapter is highly recommended for PC protection (see **GS500**)

3 Launch the PC software using E-SW-SETUP icon:

- PC software does NOT detect valid connection** communication is not established, please follow wizard procedure
- PC software detects valid connection** communication automatically established - valve is **ON-LINE** see

4 In **ON-LINE** - Wizard press button:

- a** : **WIRELESS CONNECTION** Wizard procedure for connection via Bluetooth
- b** : **CABLE CONNECTION** Wizard procedure for connection via USB cable

5 Communication established, valve is **ON-LINE** and it is possible change parameters

NOTE: for **BC, BP, EH, EW, EI, EP** please also refer to the following parameter settings:

- see step 4.2 to change the network setup
- see step 4.3 to change the reference signals setup

E-SW-SETUP PROGRAMMING SOFTWARE

ON-LINE - Wizard

- a** WIRELESS CONNECTION
- b** CABLE CONNECTION

OFF-LINE - Demo mode

SETTING FILE ARCHIVE

ON-LINE - Manual

Mandatory for direct connection to CANopen or PROFIBUS DP

NOTE: for more info about E-A-BTH Bluetooth adapter, please refer to STARTUP BLUETOOTH guide

REMARK: once removed the E-A-BTH Bluetooth adapter or E-C-SB-USB/M12 USB cable, screw the plastic protection cap **P5** applying the correct tightening torque, in order to preserve valve's IP protection characteristics

Tightening torque

0,6 Nm

4.2 FIELDBUS - Network Management - only for BC, BP, EH, EW, EI, EP

Node, Station Alias, IP Address, Baudrate, etc... can be set through:

1) Machine central unit (master) - please refer to E-MAN-S-** fieldbus protocol programming manual

2) E-SW-SETUP software

- browse to **Network Management - Configuration** to change below default settings:

Configuration	Configuration file
BC CANopen	EDS
BP PROFIBUS DP	GSD
EH EtherCAT	XML
EW POWERLINK	XDD
EI EtherNet/IP	EDS
EP PROFINET	GSDML

NOTE: configuration files are available in MyAtos area - www.atos.com

4.3 REFERENCES - only for BC, BP, EH, EW, EI, EP

The source of reference signals for valves with fieldbus:

- is preset as **Analog** by factory default
- can be managed through machine control unit by setting the source from **Analog to Fieldbus**

1 For **SN, SP, SF, SL** with fieldbus:
in **Flow** - Reference select **Fieldbus**

2 Only for **SP, SF, SL** with fieldbus:
in **Pressure/Force** - Reference select **Fieldbus**

Signals

Reference - Analog

Setpoint - 0,0 %

Demand - 0,0 %

Actual - 0,0 %

PID Out - 0,3 %

Pressure

Reference - Analog

Setpoint - 0,0 %

Demand - 0,0 %

Actual - 0,0 %

PID Out - 0,0 %

Press. PID

PID1

Pilot - 0,0 %

0,0 %

0,0 %

Driver Memories

Valve - User

Driver Status - Active

Status - Active

Alarm - No Alarm

Stored Alarms

4.4 p/Q SETUP - only for SP, SF, SL

The scaling procedure of the remote transducers feedbacks and pressure/force PID tuning are mandatory! Please refer to E-MAN-RI-LES-S operating manual.

WARNING: the system may be damaged and/or perform uncontrolled movements, due to vibrations and/or undesired transitions between controls **p** and **Q** or not executing at all the pressure/force limitation, if the operations listed in this paragraph are not performed.

4.5 SMART TUNING - E-SW-SETUP

Smart tuning allows to adjust the valve dynamic response in order to match different performance requirements.

The valve is provided with 3 factory setting for the spool control:

- dynamic** fast response time and high sensitivity for best dynamic performances (default factory setting)
- balanced** average response time and sensitivity suitable for major applications
- smooth** attenuated response time and sensitivity to improve control stability in critical applications or in environments with electrical disturbances

NOTE: smart tuning function not available for DPZO-TES valves

Spool Stroke

Time

1 = dynamic
2 = balanced
3 = smooth

4.6 STORE

Parameters modifications will be stored into driver permanent memory:

- press **Memory Store** button to access **Driver - Memory Save** window
- press **Save User Set** button to store **Valve Parameters**

WARNING: during valve parameters storing operations, the driver automatically shuts down the solenoid power supply for a short time. Do not perform any storing commands while the system is working.

4.7 BACK UP

Parameter modifications will be saved into PC memory:

- press **Save** button to access **Computer SW Archive - Setting Files** page, **Setting File Name** pop-up appears
- input a valid name into **Description** field and press **Ok** button

STEP 5 MOBILE APP

ATOS CONNECT for smartphones and tablets is a free downloadable app which allows quick access to valve main functional parameters and configuration via Bluetooth, thus avoiding physical cable connection and significantly reducing commissioning times.

ATOS CONNECT app requirements:

- iOS 14 / Android 9
- Bluetooth Low Energy (BLE), version 4.2 or higher
- Atos digital valves/drivers equipped with E-A-BTH Bluetooth adapter or with built-in Bluetooth

Download on the App Store

GET IT ON Google Play

EXPLORE IT ON AppGallery

TROUBLESHOOTING

Valve vibration or noise

- presence of air in the solenoid; perform air bleeding procedure – see STEP 3

The valve does not follow the reference signal

- valve is powered off, verify presence of 24 Vdc power supply
- valve is disabled, verify presence of 24 Vdc on enable pin - only for /Q and /Z options
- flow/pressure values exceeding the valve's performance limits, verify that hydraulic operating conditions are in compliance with the valve's characteristics
- spool sticking, contact Atos service center
- missing piloting pressure, verify that hydraulic power level is compliant with valve's characteristics
- wrong pilot/drain configuration - check if the pilot/drain configuration of the valve corresponds to the effective system layout

PC software parameters modifications are lost when valve is switched off

- parameter store operation was not performed, check store procedure – see STEP 4, section 4.6

PC software parameters modifications have no effect on the valve

- valve is OFF LINE, check connection procedure – see STEP 4, section 4.1

After the modifications of PC software parameters the valve does not work properly

- restore valve factory parameters using 'Load Factory Set' button, located in 'Driver - Memory Save' window:
 - during restore, the current to the solenoid(s) will be temporarily switched to off!
 - factory parameters will be applied at next driver restart or after power off-on sequence!